

INFLATABLE STANDUP PADDLE BOARD USER MANUAL



For your own safety and that of your equipment, make sure to take the following precautions. Failure to follow warning notices and instruction may result in property damage, serious injury or death.

GENERAL PADDLING INFORMATION

This manual has been compiled to help you operate your Inflatable Stand Up Paddle Board (Hereinafter referred to as ISUP) with safety and pleasure. It contains details of the ISUP, the equipment supplied, and information on their operation. Please read it carefully and familiarize yourself with the ISUP before using it.

SAFETY

There is a risk of serious injury or death from drowning. Paddle sports can be very dangerous and physically demanding. The user of this product acknowledges, understands, and assumes the risks involved in paddle sports. Observe the following warning labels and safety standards carefully whenever using this product.



AM Official Site



AM HOW-TO Guide



AM Service Center List

WARNING LABEL INSTRUCTIONS















MANDATORY INSTRUCTION

- Wear personal flotation device
- Read instructions first
- Fully inflate all air chambers
- Numbers of users
- Max. load capacity
- Safe distance to shore 150 m (492.1')













PROHIBITION INSTRUCTION

- Do not use in white water (except BT-22RP)
- Do not use in breaking waves (except BT-22WA)
- Do not use in offshore current
- Do not use in offshore wind
- Not for children 14 years old and below (except BT-22VIP)







ATTENTION / DANGER / WARNING

- Design working pressure
- No protection against drowning





MANDATORY INSTRUCTION

Swimmers only

CN-ORP

Item No.:


Oriental Recreational Products (Shanghai) Co., Ltd. 1699 Daye Road, Fengxian Shanghai, China 201402

PRODUCT SERIAL NUMBER

- Item No.
- Manufacturer information

		ALL-A	ROUN	TOURING			RACING						
		A CONTRACTOR	ADDA AATTA						0 0		Manual Annual Co	M A A A A A A A A A A A A A A A A A A A	
BREEZE BT-23BRP	VAPOR BT-23VAP	FUSION BT-23FUP	MONSTER BT-23MOP	CORAL BT-23COPR BT-23COPN	BEAST BT-23BEP	MAGMA BT-23MAP	ATLAS BT-23ATP	CORAL TOURING BT-23CTPR BT-23CTPN	HYPER BT-23HY01	HYPER BT-23HY02	RACE BT-21RA01	RACE BT-21RA02	
9'10"	10'4"	10'10"	12'0"	10'2"	10'6"	11'2"	12'0"	11'6"	11'6"	12'6"	12'6"	14'0"	
30"	31''	32"	33"	31"	32"	33"	34"	31"	31"	32"	27"	27"	
4.7"	6''	6''	6''	4.7''	6"	6''	6''	6"	6"	6"	6"	6"	
300 cm 76 cm 12 cm	315 cm 79 cm 15 cm	330 cm 81 cm 15 cm	366 cm 84 cm 15 cm	310 cm 78 cm 12 cm	320 cm 81 cm 15 cm	340 cm 84 cm 15 cm	366 cm 86 cm 15 cm	350 cm 79 cm 15 cm	350 cm 79 cm 15 cm	381 cm 81 cm 15 cm	381 cm 69 cm 15 cm	427 cm 69 cm 15 cm	
FIN	1 SLIDE-IN CENTER FIN				1 SWIFT ATTACH CENTER FIN				1 SWIFT ATTACH RACING FIN			1 SLIDE-IN RACING FIN	
VOLUME 229 L	315L	338L	390L	238L	312L	340L	398L	328L	330L	370L	320L	360L	
220 LBS 100 KG	308LBS 140KG	330LBS 150KG	374LBS 170KG	231LBS 105KG	308LBS 140KG	330LBS 150KG	396LBS 180KG	286LBS 130KG	330LBS 150KG	374LBS 170KG	330LBS 150KG	352LBS 160KG	
MAX. AIR		JRE		15 PSI 15 PSI			15 PSI / 15 PSI 10 PSI (center chamber)			18 PSI			

	RIVER	SURF	WINDSURF		MULTI-I	PERSOI	V	FITN	ESS	FISHING	KID
A CONTRACTOR OF A CONTRACTOR O					TAUK MALAN	Mee Pa		Yoga Dock BT Outer Diamete Inner Diamete Thickness: 120	er: 290cm/9'6" r: 170cm/67"	DESCRIPTION OF THE PROPERTY OF	
RACE ELITE BT-22RE	RAPID BT-22RP	WAVE BT-22WA	BLADE BT-22BL	SUPER TRIP BT-21ST01	SUPER TRIP TANDER BT-20ST02	MEGA BT-20ME	AIRSHIP RACE BT-20AS	DHYANA BT-23DHP	PEACE BT-23PC	DRIFT BT-20DRP	VIBRANT BT-22VIP
14'0" 25" 6"	9'6" 33" 6"	8'8" 30" 4"	10'6" 33" 6"	12'2" 32" 6"	14'0" 34" 6"	18'1" 60" 8"	22'0" 34" 8"	10'8" 34" 6"	8′2″ 35″ 6″	10′10" 38" 6"	8'0" 28" 4"
427 cm 63.5 cm 15 cm	289 cm 84 cm 15 cm	265 cm 75 cm 10 cm	320 cm 84 cm 15 cm	370 cm 82 cm 15 cm	427 cm 86 cm 15 cm	550 cm 152 cm 20 cm	670 cm 87 cm 20 cm	325 cm 86.5 cm 15 cm	250 cm 90 cm 15 cm	330 cm 97 cm 15 cm	244 cm 71 cm 10 cm
1 FIBERGLASS RACING FIN	1 RIVER FIN + 4 FIXED FINS	1 SURF CENTER FIN + 2 SIDE FINS	1 CENTER FIN + 1 DAGGER FIN	1 CENTER FIN	2 CENTER FINS	5 CENTER FINS	1 RACING FIN	1 SWIFT ATTAC CENTER FIN	CH /	1 CENTER FIN	1 CENTER FIN
330L	300L	161L	350L	400L	500L	1400L	1000L	347L	340L	284L	140L
330LBS 150KG	286LBS 130KG	209LBS 95KG	330LBS 150KG	462LBS 210KG	507LBS 230KG	1433LBS 650KG	1014LBS 460KG	341LBS 155KG	330LBS 150KG	286LBS 130KG	132LBS 60KG
18 PSI	18 PSI	18 PSI	18 PSI	15 PSI	18 PSI	8 PSI	18 PSI	15 F	PSI	15 PSI (board) / 3PSI (side air chambers)	15 PSI



Actual configuration may vary upon different models.

ACCESSORIES

STANDARD

Zip Backpack



Double-action Pump (Mega/Airship Race/ Super Trip Tandem x 2)



Fin Megax

(Mega x 5/ Super Trip Tandem x 2/ Wave x 3/ Blade x 2)



Cargo Bungee Cord (except Wave)



Repair Kit





Leash (except Super Trip/ Super Trip Tandem/Mega/ Airship Race/Peace/Yoga Dock)

*Actual configuration may vary upon different models.

DRIFT

Fishing Rod Holder x 2



Paddle Holder



MEGA/YOGA DOCK



CORAL/CORAL TOURING/YOGA

2-in-1 Carry Strap



Paddle Holder (Only for Dhyana)



Straps x 3 (Only for Dhyana)




PADDLE

Paddle (excluded from Race/Race Elite/Hyper/Rapid/Super Trip/Mega/Airship Race/Blade/Wave/Peace/Super Trip Tandem)




INSTRUCTION FOR ASSEMBLING AND DISASSEMBLING

INFLATION



Open the valve cap by twisting counter-clockwise. Ensure the valve is clear from debris, sand, or dirt before releasing.



Push valve button in and turn 90 degrees.




OR




Valve button popping up to the "UP position" for inflation.


Valve button locked in "DOWN position" for deflation.



Attach - Attach the pump hose to the pump and secure it tightly.




Connect - Attach the end of the pump hose to the valve and twist 45° clockwise to lock in place.




Save Effort - As pressure builds, keep arms extended and bend the knees to power for less effort.



LIQUID AIR V1




Fast Inflation - Use DOUBLE ACTION position by closing the air-tap to pump the board up to 7-10 psi.




Easy Inflation - Switch to SINGLE ACTION position by removing the air-tap for easier inflation.



LIQUID AIR V2



Fast Inflation - Use DOUBLE ACTION mode with the top cap displaying "2" to pump the board up to 7 - 10 psi.



Easy Inflation - Rotate the switch to SINGLE ACTION mode with the top cap displaying"1" for easier inflation.

Note: Gauge will not respond until reaching 4psi. Just keep pumping for 2-3 minutes!



Max. Pressure -Keep pumping the board until you reach 15-18 psi.



12PSI minimum (8PSI for MEGA/ 10PSI for HYPER inner chamber) for proper inflatable boards operation and 15PSI maximum (18PSI for SUPER TRIP TANDEM/ RAPID/ RACE/ RACE ELITE/ WAVE/ BLADE/ AIRSHIP RACE). Over inflation will void your warranty.




After inflation, return the valve cover and tighten in clockwise direction to lock in place.

Warning:

Do not leave your board under direct sunlight as this may cause over-inflation.

Please keep the board under shade when not in use with a working pressure NO MORE THAN 10psi, or leave your board in a cool dry place.

Remember to check the air pressure before and after use, and deflate your board when necessary.



For Double Chamber Board (HYPER)

For best performance, the double chamber should always be inflated to ensure the highest stiffness and safety.

- Inflate the inner chamber up to 10 PSI.
- Inflate the outer chamber up to 15 PSI.

PRECAUTION & TIPS


- Electric Pumps can be used to inflate board up to 80-90%. However, the remaining pressure required should be achieved by using the hand pump to avoid over-inflation.
- Do not use air compressors as this voids warranty of board.
- Before long trips, ensure the board has been inflated and has maintained pressure for a minimum of 24 hours.

FIN INSTALLATION

Slide-in Center Fin System



SLIDE - Slide in the large Center Fin to the fin base.




INSERT - Insert the push-in pin.

Swift Attach Fin System

(CORAL/BEAST/MAGMA/ATLAS/CORALTOURING/HYPER/WAVE/DHYANA)



SLOT IN - Align the fin base into the fin box slot and slide to the front edge.




PRESS - Keep pressing the lever on the rear and push the fin down.




SNAP - Lock the fin in place with the snap.

NOTE: Install the WAVE side fins as suggested below.



US Fin System (RACE ELITE)



WASHER - Place the washer into the fin box and slide it to the front.



SLOT IN - Align the fin base into the fin slot and slide to the rear of the fin box.




LINE UP - Push the fin down and line up the washer hole with the screw.



SCREW - Secure firmly by screwing.

DEFLATION







Valve Open - Open the valve cap and twist the valve button for "DOWN POSITION". Ensure the valve is clear from debris, sand, or dirt before releasing.




Deflate (by hands) - Roll the board from nose to tail to squeeze the air out.



Deflate (by pump) - Use the pump on "DEFLATE" position.



Roll - Roll the board around the pump. Make sure the pump is settled in the middle.



Roll - Follow the folding line indication for first fold, and roll the board from nose to tail.



Pack - Use the webbing strap to secure the neatly rolled board in place, but do not overtighten the strap. Place the accessories in the pocket.


or

YOGA DOCK INSTRUCTION

YOGA DOCK and DHYANA Connection


Each DHYANA yoga board can be connected to this YOGA DOCK by three straps. For each strap, follow connection instruction shown below.


- Link up the clasp (a) with D-ring (b) on the board. Thread the strap through D-ring (c) on the dock.
- 2. Thread the strap through the buckle (d) and fasten.
- 3. Repeat above steps for the rest straps.



Folding and Storage

- 1. Fold the Yoga Dock as shown below.
- 2. Pack the Yoga Dock into the carry bag.












PADDLE ASSEMBLY









- ACE B0303622

 Adjustable Aluminum iSUP Paddle for Kids
- **SPORTS III** B0303922 Adjustable Aluminum iSUP Paddle
- PASTEL B0303923/24/25
 Fiberglass / Carbon iSUP Paddle
- **SOLID** B0303013 Fiberglass iSUP Paddle
- CARBON GUIDE B0303014
 Carbon / Fiberglass
 iSUP Paddle
- CARBON PRO B0303015 Carbon iSUP Paddle




• CARBON X B0303016 2PCS Carbon iSUP Paddle




• DUAL-TECH
B0303011
2-in-1 iSUP & Kayak
Paddle


HOW TO WEAR A SAFETY LEASH



STANDARD LEASH INSTALLATION



COIL/SURF/RIVER LEASH INSTALLATION



HOW TO TAKE CARE OF ISUP BOARD

DO'S

DON'TS

CLEANING

Clean the board after each use with freshwater and mild soap.





DON'T USE AN AIR COMPRESSOR

You can easily over-inflate the board by using an air compressor and void the warranty.

KEEP IT DRY

Dry the board after each use, especially before storing to avoid mould damage.





NO DRAGGING

Don't drag the board as sharp debris may puncture it.

FREQUENT USE

Use the board frequently as long-term storage may cause adhesive failure.





AVOID DIRECT SUNLIGHT

Keep the board under shade when not in use with a working pressure less than 50%-60% of the max. air pressure.

REGULAR MAINTENANCE

Regularly check for cracks, scrapes, or any other issues and repair if necessary.





AVOID TEMPERATURE EXTREMES

Keep the boards sheltered away from temperature extremes and humidity. Store at room temperature between 0°C - 40°C.

FAQs (Frequently Asked Questions)

Q: How much air should I pump into my board, and how long does it take to inflate?

A: The maximum pressure is 15 - 18 PSI (8 PSI for MEGA, 10 PSI for HYPER inner chamber, 3 PSI for DRIFT side chambers), any higher you risk over inflating and damage. Depending on the size of your board it can take anywhere from 5 to 8 minutes.

Q: When detaching the pump from the board, the air starts to release from the valve. How do I stop this from happening?

A: The air is releasing as the valve spring pin has been left in the deflating position. Simply push down and turn the pin until it lifts up into the inflation position and stops air from releasing; continue to inflate the board until up to pressure.

HOW TO REPAIR A CUT OR PUNCTURE IN YOUR INFLATABLE BOARD




SUPPLIES REQUIRED

- Glue (AQUASEAL® is recommended)
- Acetone or methyl ethyl ketone (M.E.K.)
- Hairdryer
- Brush
- Tape
- Spatula or spoon
- Towel

(Not provided in the SUP board package)








- 1. Clean the area around the cut or puncture using acetone or M.E.K.
- 2. Draw the outline of the patch using chalk or pencil (do not use ink). Cut the patch, cover the cut or puncture with approximately 2.5cm (1 inch) overlap on all sides.
- 3. Apply tape along the outline of the patch. This will prevent the glue from spreading outside the patch area.







4. Apply glue on both the board and patch using a brush or other applicator. Make sure the glue is spread evenly and completely over the board and patch. Let the glue dry for 5 minutes.

- 5. Apply the patch starting on one side and move towards the other side Be careful not to trap any air bubbles.
- 6. Use a hairdryer to gently heat the area to ensure a good bond between the patch and the board.


Use a metal spatula or spoon and firm pressure to ensure a good bond and to remove any air bubbles.



Allow the glue to cure with the board un-inflated for 24 hours prior to use.

HOW TO FIX A LEAKING VALVE


A. Try to tighten the valve




- Inflate your board up to the max air pressure
- 2. Stick your valve wrench down inside of valve and turn clockwise to tighten the valve back down onto the board

B. Re-install or replace a valve





- 1. Completely deflate your board
- 2. Undo the dust cap and insert the valve wrench into the valve and twist counterclockwise to remove the valve



- 3. Check the rubber ring to make sure that it is in the correct position, tight around the valve and there is no debris in the way
- 4. Be sure the pin spring is functioning properly and that there are no cracks along the edges



- 5. Ensure there are no strings from the drop stitching material
- 6. Note the bottom piece of the valve is not attached to anything
- 7. Fit the valve back into your board
- 8. Align all the threads and twist to tighten
- 9. Once the valve is hand tight, use the valve wrench to seal completely



NOTE: Correctly use the wrench by pressing it with one hand on top.

WARRANTY



AM warrants this product to be free from major defects in material or workmanship to the original purchaser for a period of **2-year** (board ONLY) from the date of purchase. This warranty is subject to the following limitations.

- 1. The warranty is valid only when this product is used for normal recreational activities and does not cover products used in rental or school operations.
- 2. AM will make the final warranty determination, which may require inspection and/or photos of the equipment, which clearly show the defect(s). If necessary, this information must be sent to the AM distributor in your country with prepaid postage. Product can be returned only if a return authorization number is given in advance by the AM distributor. The return authorization number must be clearly labelled on the outside of the package, or it will be refused.
- 3. If a product is deemed to be defective by AM, the warranty covers the repair or replacement of the defective product only. AM will not be responsible for any costs, losses, or damages incurred as a result of loss or misuse of this product.
- 4. This warranty does not cover damage caused by misuse, abuse, neglect, normal wear and tear including, but not limited to punctures, damage due to excessive heat exposure, damage caused by improper handling and storage, damage caused by use in waves or shore break, board breakage caused by filling or crashing in surf conditions, or damage caused by anything other than defects in material and workmanship.
- 5. This product must not be modified and/or fitted with a motor except AM BlueDrive power fin.
- 6. This product must not be used in excess of the manufacturers recommended maximum load capacity.
- 7. This warranty is void if any unauthorized repair, change or modification has been made to any part of the equipment.
- 8. The warranty for any repaired or replacement equipment is good from the date of the original purchase only.
- 9. The original purchase receipt must accompany all warranty claims. The name of the retailer and date of purchase must be clear and legible.
- 10. There are no warranties that extend beyond the warranty specified here in.



This product is designed in accordance with standards for a specific use. Any modifications or transformations higher than that indicated by the manufacturer could result in serious risks for the user and will void the warranty.