

# 25 ProStar # HWN111

REPLACES # AXV016P



Pod Plugs (6 Pack)

# 26 ProStar # HWN117xx

REPLACES # AXV604WHP



Wing Kit: Left and Right Wings

# 27a ProStar # HWN114

REPLACES # AXV413P



Pod Shoes: Vinyl and Fiberglass (4 Pack)

# 27b ProStar # HWN115

REPLACES # AXV414P



Pod Shoes: Concrete (4 Pack)

# 28 ProStar # HWN148

REPLACES # AXV314P



Captive Screw / Retaining Clip

# 29a ProStar # HWN149xx

REPLACES # AXV603



Fixed Access Cover Assembly for Concrete Models

# 29b ProStar # HWN149Vxx

REPLACES # AXV603A



Fixed Access Cover Assembly for Vinyl Models

# 30 ProStar # HWN116xx

REPLACES # AXV417WHP



Pod Kit: Left and Right Pods, Plugs, Screws, Washers