

## Commercial Series anchors



**Tri Point Anchor**- used for the following:

**New construction**- can be installed when the concrete is being poured.

**Paver decks**- A pad of concrete will need to be poured for this install in most situations so the anchor can be installed when the pad is poured.

If the existing concrete is not 6" deep or is not in good condition a section of the deck (40" x 40") would be cut out and re poured to the 6" depth and the anchor is installed when it is poured.



**Retro Fit Anchor**

Is used for an existing concrete deck that has the required 6" of concrete.

The install is a core drilling method.



**Drop in anchor**- this is an easy install for an existing deck, however these anchors cannot be bonded. The lift itself must be bonded. If they are unsure how to do this they need to contact a local electrician.