

COMPU POOL CPSC HALF LEAD KIT

1. Cut off and remove the old connectors that are being replaced with the Half Lead Kit.
2. Strip back the outer jacket on the wires by 0.40" (10mm).
3. Slide the large heat shrink over the cable.
4. Using a crimping tool (do not use pliers), crimp the wires to the copper links.
5. Slide the smaller heat shrink over each copper link and shrink with a heat gun.
6. Slide the larger heat shrink over the 3 copper links and shrink with a heat gun.
7. If brass connectors are a loose fitting then close the female receptacle slightly with pliers.

THERE MUST BE A FIRM FITMENT

compu pool