



1. Use 1.5" PVC to supply water to the bowl. Cut PVC leaving 1in protruding above the surface where the bowl will be mounted.



2. Glue Flange to the 1.5" in PVC pipe



3. Place the concrete bowl over flange.



4. First place the foam gasket over the flange. Second place the washer on top of the foam gasket. Third thread the nut to the flange



5. Hand tighten nut
6. Using channel locks turn nut 1/4 turn.
7. Adjust as needed to make water-tight. Do NOT over tighten!!!!



8. Thread in the diffuser to the female threads of the flange. Hand tighten.