





CMP 25677-530-950; 25677-630-950; 25677-730-950; 25677-830-950





INSTRUCTION MANUAL


- 1. Remove access door carefully
 - 2. Pull wire plug from channel
 - 3. Unscrew plug to separate it from the main power cable





- 4. Pull the LED Strip from channel (some models may include a retaining clip)
- 5. On longer models, feed pull wire from opposite side











- 8. Reattach plug to main power cable. Put wire back into channel
 - 9. Reinstall access door

