PAL TOUCH PCT-1 TRANSMITTER

PAL LIGHTING

PAL COLORTOUCH

ON / OFF

COLOR WHEEL

Can select any color from the color wheel.
Can select Brightness (B) on any selected color.

OPERATIONAL RED LED

Flashes when any remote operation is initiated

MODE SELECTION
 Up & Down

1. White - Can change Brightness (B) [Default]
2. Color Change - Can change Brightness (B) & Speed (S)
        Red, Amber, Green, Aqua, Blue, Purple, White
        with initial setting of 2 second delay.
        This time can be increased to 4, 6, 8 or 10 Sec
        by pressing (S -)
3. Disco - Can change Brightness (B)
4. White Gradual Change - Can change Brightness (B) & Speed (S)
5. Blue Gradual Change - Can change Brightness (B) & Speed (S)
6. Green Gradual Change - Can change Brightness (B) & Speed (S)
7. Red Gradual Change - Can change Brightness (B) & Speed (S)

53

110

DEPTH = 20mm

PCT-1

BRIGHTNESS
 Up & Down
5 Brightness Settings
(100%, 80%, 60%, 40%, 20%)

SPEED
Up & Down
 5 Speed Settings
 (2 sec, 4 sec, 6 sec, 8 sec, 10 sec)

FEATURES

1. Matching Code - Apply power to the receiver. Then press (+) on Speed (S) once within 5 seconds.
        The output light will flash white 3 times if matching is successful.
2. Clearing Code - Apply power to the receiver. Hold down (+) on Speed (S) for 3 seconds.
        The output light will flash 6 times if clearing the code is successful.
        After successfully clearing the existing code a new code will have to be applied
        by following the matching code procedure above.
3. 1 Transmitter (PCT-1) can operate an unlimited number of Receivers (PCR-4)
4. 1 Receiver (PCR-4) can be controlled by a maximum of 4 Transmitters (PCT-1)
5. Touching the color wheel will reset any Mode selection.
6. Memory Feature - Remembers color selection after being switched off.
7. Once the transmitter and receiver are successfully coded the receiver will remember the code if powered off.