


PAL TOUCH PCT-5 TRANSMITTER



PUBLICATION NO. P42-50AU



ON / OFF (For Channel 5 only)

COLOR WHEEL

Can select any color from the color wheel. Can select BRIGHTNESS on any selected color.

OPERATIONAL RED LED

Flashes when any remote operation is initiated

MODE SELECTION Up & Down

- 1. White Can change BRIGHTNESS [Default]
- 2. Color Change Can change BRIGHTNESS & SPEED

Red, Amber, Green, Aqua, Blue, Purple, White with initial setting of 2 second delay.

This time can be increased to 4, 6, 8 or 10 Sec by pressing (SPEED DOWN)

- 3. Disco Can change BRIGHTNESS
- 4. White Gradual Change Can change BRIGHTNESS & SPEED
- 5. Blue Gradual Change Can change BRIGHTNESS & SPEED
- 6. Green Gradual Change Can change BRIGHTNESS & SPEED
- 7. Red Gradual Change Can change BRIGHTNESS & SPEED

BRIGHTNESS Up & Down

5 Brightness Settings (100%, 80%, 60%, 40%, 20%)

SPEED Up & Down

5 Speed Settings

(2 sec, 4 sec, 6 sec, 8 sec, 10 sec)

CH1 7 0 CH2 CH3

CH4

On-Off Control for PCR-5 4ch Remote

Control System

FEATURES

1. Matching Code - Apply power to the receiver. Then press (SPEED UP) once within 5 seconds.

The output light will flash white 3 times if matching is successful.

2. Clearing Code - Apply power to the receiver. Hold down (SPEED UP) for 3 seconds.

The output light will flash 6 times if clearing the code is successful.

After successfully clearing the existing code a new code will have to be applied by following the matching code procedure above.

- 3. 1 Transmitter (PCT-5) can operate an unlimited number of Receivers (PCR-4)
- 4. 1 Receiver (PCR-4) can be controlled by a maximum of 4 Transmitters (PCT-5)
- 5. Touching the colour wheel will reset any Mode selection.
- 6. Memory Feature Remembers color selection after being switched off.
- 7. Once the transmitter and receiver are successfully coded the receiver will remember the code if powered off.

FAX: (02) 9531 2666