



**ON / OFF**  
Turns On and Off both Channel 1 & Channel 2

**OPERATIONAL RED LED**  
Flashes when any remote operation is initiated

**MODE SELECTION**  
- By pressing (M +) once the mode selection advances

Fixed Color Selection Guide			
Mode 1.	<b>White [Default]</b>	<b>Blue</b>	<b>Color Change</b>
Mode 2.	Color Change	White	White
Mode 3.	Blue	Color Change	Blue
Mode 4.	Green	Green	Green
Mode 5.	Red or Aqua	Red or Aqua	Red or Aqua
Mode 6.	Amber	Amber	Amber
Mode 7.	Purple	Purple	Purple
Mode 8.	Disco	Disco	Disco

Note: The LED lamp is fitted with Dip switches to set the default color. See Pool Light instructions to obtain detail.

**CHANNEL 1 SELECTION**

(ON) Ch1 Turns on Channel 1  
(OFF) Ch1 Turns off Channel 1

**CHANNEL 2 SELECTION**

(ON) Ch2 Turns on Channel 2  
(OFF) Ch2 Turns off Channel 2

Note 1: Channel 1 & Channel 2 On/Off Selection can be made independent to the main On/Off switch  
Note 2: The On/Off on Channel 1 & Channel 2 can be used to advance the color selection to select different color on Channel 1 & Channel 2.

**FEATURES**

1. Matching Code - Apply power to the receiver. Then press (ON) on Channel 2 once within 5 seconds. The output light will flash 2 times if matching is successful.
2. Clearing Code - Apply power to the receiver. Hold down (ON) on Channel 2 for 3 seconds. The output light will flash 3 times if clearing the code is successful. After successfully clearing the existing code a new code will have to be applied by following the matching code procedure above.
3. 1 Transmitter (PCT-3) can operate an unlimited number of Receivers (PCR-8A)
4. 1 Receiver (PCR-8A) can be controlled by a maximum of 4 Transmitters (PCT-3)
5. Once the transmitter and receiver are successfully coded the receiver will remember the code if powered off.