



NEXA FILL™

Automatic Water Level Control

Finally... a way to keep the water in your swimming pool at a constant level with the Nexa Fill automatic water level control. The Nexa Fill requires no permanent installation and it is fully adjustable.



The unit connects to a reinforced garden hose and is placed over the side of the swimming pool. Turn the water on to the hose and the Nexa Fill stands guard over your water level, adding water as needed and never over-filling. The Nexa Fill is the perfect solution for vacations, leaking swimming pools, vacation homes, or just plain busy people.

