

Calibration instructions for the CompuPool generic salt cells compatible with Hayward® T-CELL® series:

1. Turn the main switch from “Auto” to “Off”, and then back to “Auto”.
2. Wait for about ten seconds, until you hear a click inside the panel.
3. Once you hear the click, immediately push the “diagnostics” button five times until a negative number is displayed – starting high, and automatically scrolling down.
4. As it is scrolling down, once it reaches the number at which you know the pool salt level is actually at, move the main switch to “SUPER CHLORINATE”, then back to “AUTO”. This will re-calibrate your panel to the accurate salt level.