



# IntelliChem™

## Water Chemistry Controller for Swimming Pools



## Installation and User's Guide

**IMPORTANT SAFETY INSTRUCTIONS  
READ AND FOLLOW ALL INSTRUCTIONS  
SAVE THESE INSTRUCTIONS**

## Technical Support

Phone: (800) 831-7133 - Fax: (800) 284-4151

visit [www.pentairpool.com](http://www.pentairpool.com) and [www.staritepool.com](http://www.staritepool.com):

CONTENTS	
<b>IMPORTANT WARNING AND SAFETY INSTRUCTIONS .....</b>	<b>i</b>
IntelliChem Overview .....	1
Operator Controls Indicators and Alarm LEDs .....	2
pH Settings and ORP Settings Buttons .....	3
Auto Setup .....	6
IntelliChem Menus .....	9
pH Menu .....	11
ORP Menu .....	14
Configuration Menu .....	17
Saturation Index .....	24
Installation .....	28
Setting up IntelliTouch Automation Control System .....	43
Setting up EasyTouch Automation Control System .....	45
Setting up SunTouch Automation Control System .....	46
Troubleshooting .....	46
Maintenance .....	51
Replaceable Parts List .....	54

© 2011 Pentair Water Pool and Spa, Inc. All rights reserved.

1620 Hawkins Ave., Sanford, NC 27330 • (919) 566-8000

10951 West Los Angeles Ave., Moorpark, CA 93021 • (805) 553-5000

IntelliChem™, IntelliFlo®, IntelliTouch®, EasyTouch®, SunTouch®, IntelliChlor® MobileTouch® and Pentair Water Pool and Spa® are trademarks and/or registered trademarks of Pentair Water Pool and Spa, Inc. and/or its affiliated companies in the United States and/or other countries. Teflon® is a registered trademark of E.I. Du Pont De Nemours and Company Corporation. Unless noted, names and brands of others that may be used in this document are not used to indicate an affiliation or endorsement between the proprietors of these names and brands and Pentair WaterPool and Spa, Inc. Those names and brands may be the trademarks or registered trademarks of those parties or others.

P/N 521363 Rev A - 02/14/11

## IMPORTANT WARNING AND SAFETY INSTRUCTIONS



**DANGER**

**SERIOUS BODILY INJURY OR DEATH CAN RESULT IF THIS PRODUCT IS NOT INSTALLED AND USED CORRECTLY.**



**DANGER**

**INSTALLERS, POOL OPERATORS AND POOL OWNERS MUST READ THESE WARNINGS AND ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.**



**WARNING**

Most states and local codes regulate the construction, installation, and operation of public pools and spas, and the construction of residential pools and spas. It is important to comply with these codes, many of which directly regulate the installation and use of this product. Consult your local building and health codes for more information.



**IMPORTANT NOTICE - Attention Installer:** This Installation and User's Guide ("Guide") contains important information about the installation, operation and safe use of this product. This Guide should be given to the owner and/or operator of this product.



**WARNING**

Before installing this product, read and follow all warning notices and instructions in this Guide. Failure to follow warnings and instructions can result in severe injury, death, or property damage. Call (800) 831-7133 for additional free copies of these instructions. Please refer to [www.pentairpool.com](http://www.pentairpool.com) for more information related to this products.



**DANGER**



### **RISK OF ELECTRICAL SHOCK OR ELECTROCUTION:**

**BEFORE WORKING ON INTELLICHEM! Always disconnect power to the IntelliChem controller at the circuit breaker before servicing. Failure to do so could result in death or serious injury to service person, pool users or others due to electric shock.**

**BE SURE TO DISCONNECT ALL SUPPLY CONNECTIONS BEFORE SERVICING INTELLICHEM. AC Power may be supplied to the relay terminals Ex\_Relay1 and Ex\_Relay2 from other sources. See page 31 for details.**

This product must be installed by a licensed or certified electrician or a qualified pool professional in accordance with the National Electrical Code (NEC), NFPA 70 or the Canadian Electrical Code (CEC), CSA C22.1. All applicable local installation codes and ordinances must also be adhered to. Improper installation will create an electrical hazard which could result in death or serious injury to pool users, installers or others due to electrical shock, and may also cause damage to property.



**WARNING**

**DO NOT PERMIT CHILDREN TO OPERATE THIS EQUIPMENT!**



**WARNING**

When mixing acid with water, ALWAYS ADD ACID TO WATER. NEVER ADD WATER TO ACID. When adding any chemical to the pool/spa, be sure to follow the manufacturer's instructions thoroughly.



**WARNING**

**DO NOT MIX SODIUM HYPOCHLORITE AND MURATIC ACID**



**WARNING**

Risk of electrical shock. Connect IntelliChem to a ground-fault interrupter-circuit (GFCI). Contact a qualified electrician if you cannot verify that the receptacle is protected by a GFCI.

## IMPORTANT WARNING AND SAFETY INSTRUCTIONS



**WARNING CHEMICAL BURN HAZARD:** Make sure all pumps are switched off at the main circuit breakers at the house before drilling into any pipes. Securely fasten all electrical, water and chemical lines. Locate chemical feed pumps and chemical storage tanks in a safe and secure area.

**When using IntelliChem with a pool pump timer:** The Association of Pool and Spa Professionals (APSP) recommends that all water in a residential pool pass through the filtration system at least once every 12 hours (referred to as pool water turnover). However, many factors have an effect on actual pump and filter system run times. Pool size, source of water, direct sun light, indoor/outdoor, screened and un-screened, filtration system, cold or hot weather, swimmer load, rain, organic debris, algae, etc., are all factors which contribute to either more or less pool pump and filter system run times. Because of these differences, it is extremely difficult to set an initial run time (starting point) for the pool pump and chlorinating system. Try initially setting the pool pump timer to 12 hours. It will take a few days to get just the right amount pool pump operating time. When the Chlorinator is wired with a pool pump timer (see page 6) results will vary greatly from one pool installation to the next, so this should be discussed with either the pool builder or your pool professional.

### Using Acid for pH Control

Safety precautions should be used when handling Muriatic acid to control pH water levels. Muriatic acid can cause serious body injury and damage pool equipment. Extra care must be taken when installing, maintaining and operating acid pump feed systems. Acid is dangerous to handle and should be properly contained, transported, poured, stored, and dispensed. **WARNING!:**

- Strictly follow the acid manufacturers safety and handling protocols including hand, body and eye protection when transferring or handling acid.
- Check the pH and sanitizer levels of the water regularly.
- Periodically use an independent pH and Chlorine test kit to verify that pH and chlorine is at a safe level. If the pH and Oxidation Reduction Potential (ORP) or Flow Cell sensors are broken, depleted or dirty with oils, lotions, or other contaminants, they can report inaccurate results to the system causing incorrect water chemistry, which could harm people or equipment.
- Check the IntelliChem main status display each day to ensure there are no Alarm messages. See "Troubleshooting" on page 46 for more information.

### Using CO2 for pH Control

Plaster pools and pools using salt-chlorine generators typically cause a slow pH rise which must be managed. With IntelliChem, muriatic acid or carbon dioxide (CO<sub>2</sub>) is dispensed into the filter system's return water as needed until the Flow Cell pH sensor detects the proper pH level. Using CO<sub>2</sub> for pH control eliminates the need to handle and store acid and can be a safer method. As CO<sub>2</sub> gas is injected into the pool water, it dissolves and creates carbonic acid. This weak acid is very efficient at lowering pH with the added benefit of self-limiting if the CO<sub>2</sub> is over-fed.

## Overview

IntelliChem is a pH and ORP sensing device that dispenses correct amount of chlorine or bromine, muriatic acid or CO<sub>2</sub> gas. IntelliChem provides continual analysis of your swimming pool water sanitation and pH levels, providing real-time status information to dispense the proper amount of muriatic acid (pH reducer) and chlorine or bromine for the correct sanitization and pH balance. IntelliChem operates with or without a salt chlorine generator to provide a self-replenishing supply of chlorine generated from salt. IntelliChem can also connect to carbon dioxide (CO<sub>2</sub>) liquid gas tanks to lower pH in your swimming pool water. When CO<sub>2</sub> dissolves into water it produces weak neutral bicarbonate salts which reduces pH. CO<sub>2</sub> is environmentally friendly and produces no secondary pollution into the treated water by salts such as chlorides or sulfates. CO<sub>2</sub> does not corrode metal equipment and does not require any special piping. IntelliChem supports Pentair Water Pool and Spa® “Pentair” EasyTouch®, IntelliTouch® and SunTouch® automation control systems for pH and ORP control. IntelliChem also supports IntelliChlor® salt chlorine generator (SCG) to help manage your pool water sanitizer levels.

### Operating IntelliChem

Before operating IntelliChem, it's important to test and adjust your pool water chemistry to the recommended pool industry levels found in this manual (see page 19). If you are using an IntelliChlor salt chlorine generator, adjust the salt levels to the recommended levels in the IntelliChlor Installation and User's Guide (P/N 520589). During normal IntelliChem operation, no user input is required, IntelliChem will automatically sense ORP and pH levels. The current ORP and pH levels are regularly displayed on the control panel LCD display. Use the pH Settings or ORP Settings buttons to view or adjust supply levels. The IntelliChem “Auto Setup” feature provides screen prompts for first-time setup or standard configurations such as setup reminder times, calculating feed times, proportional limits and alarms. For details, see page 6.

### First Balance Your Pool Water


**IMPORTANT:** To help keep your pool water balanced follow these steps:

1. Use a Test Kit (with fresh testing reagents) to measure the **pH, alkalinity, and calcium** hardness of the pool water. For greater accuracy, Pentair recommends the AcuCheck3 Test Kit to measure pH, chlorine ppm, and alkalinity levels (P/N 7450001100). “Balanced” water has proper levels of pH, Total Alkalinity and Calcium Hardness. This “balanced” water is neither corrosive or scaling. The pH (0-14) value is the scale of relative acidity or alkalinity. Recommended pH range is from 7.2 to 7.6. The IntelliChem default pH value is 7.5 (see page 12).
2. Be sure the pool chlorine level is balanced. Ideal free chlorine level should be between 1.0 - 3.0 parts per million (ppm).
3. Use the online **Langelier Saturation Index (LSI)** calculator to diagnose the water balance in your pool or the IntelliChem built-in LSI calculator (see page 27). Refer to:  
<http://www.pentairpool.com/pool-owner/resources/calculators/langelier/>

*Note: A Saturation Index value of 0 indicates the water is chemically in balance. If the Index is a **minus (-) value, corrosive tendencies are indicated.** If the Index is a **plus (+) value, scale-forming tendencies are indicated.** A Saturation Index value between **+0.3 to -0.3** is considered satisfactory in a swimming pool. See Saturation Index menu on page 24.*

## Operator Controls, Indicator and Alarm LEDs

### CONTROL PANEL DESCRIPTION



### Control Buttons and LEDs:

- ① **Liquid Crystal Display (LCD) with LED backlighting:** Displays system status information and IntelliChem main menu. Display backlight and menu on and off time (30 seconds to 24 hours) can be set via the “LCD Timeout” menu feature. See “Configuration” menu page 17).  
**Display viewing modes:** Select between two display modes: **Basic:** pH and ORP status with alarms messages. **Advanced:** pH, ORP, status, alarm messages and process timers.
- ② **pH Settings button:** Access the pH settings (see page 3).
- ③ **ORP Settings button:** Access the Oxidation Reduction Potential (ORP) settings (see page 3).
- ④ **Flow LED:** Green LED on indicates flow is detected. LED will blink during flow delay. LED off indicates no flow in the system. If flow is not present, no chemical feeding or IntelliChem activity is allowed. LED brightness can be adjusted via the Configuration “Display Mode” menu (see page 17).
- ⑤ **Left arrow button:** Scroll through sub-menu items or move cursor left when editing a setting.
- ⑥ **Menu button:** Access the IntelliChem main menu (see page 11). While in menu mode, used to exit a menu level. All items are saved as soon as they are changed.
- ⑦ **Right arrow button:** When in menu mode, selects menu main and sub-menu item, scroll through sub-menu items or move cursor right when editing a setting.
- ⑧ **Alarm LED:** LED is on if an alarm condition occurs. Display shows alarm message and status (see page 48). LED brightness can be adjusted via the Configuration “Display Mode” menu (see page 17).
- ⑨ **Up/Down arrow button:** When in a menu mode, use ▼/▲ to scroll through main menu and sub-menu items, increase, decrease or change a setting or value. Also, used for moving to next sub-menu page 1/2 - 2/2.

## pH Settings and ORP Settings Buttons

### pH Dosage (dispense acid)

**⚠ DANGER** DO NOT manually feed pH (acid) and ORP sanitizer (chlorine) at the same time without sufficient water flow through the piping system. Combining these two chemicals without sufficient water flow for mixing will result in the formation of hazardous gas. This menu item will be displayed as **Override [Wait]** during no-flow and flow-delay time period.



**pH Settings button:** Press the **pH Settings button** to access the pH dosage settings.

**pH Settings**  
 ▶ **Override [Dose]**  
**Level Gauge:** 5  
**Limit cleared**



**ORP Settings button:** Press the **ORP Settings button** to access the Oxidation Reduction Potential (ORP) settings. The ORP is the sanitization quality of the water of a given solution.

**ORP Settings**  
 ▶ **Override [Dose]**  
**Level Gauge:** 5  
**Limit: [Clear ]**

Note: To exit pH Settings and ORP Settings, press the MENU button.

**Password Protect:** The pH Settings and ORP Settings screens are not accessible when the Password Lock is set to “ALL”. Set the Password Lock to “OFF” or “MENU” to access these screens (see page 5).

**Override (pH):** Press the **◀/▶ Right or Left arrow button** to toggle between “Dose” or “Stop”. Select “Dose” to dispense muriatic acid or CO2 and select “Stop” to stop dispensing acid or CO2 (pH Settings LED is on). To exit and save the setting, press the MENU button or press the **▼ Down button** to select the “Level Gauge” feature. The Override feature is not available when CO2 is setup to “Feed to Setpoint.”

**Override (ORP):** Press the **◀/▶ Right or Left arrow button** to toggle between “Dose” or “Stop”. Select “Dose” to dispense chlorine (or bromine) and select “Stop” to stop dispensing chlorine (ORP Settings LED is on). To exit and save the setting, press the MENU button or press the **▼ Down button** to select the “Level Gauge” feature. The Override feature is not available when IntelliChlor is setup to “Feed to Setpoint.”

**Level Gauge indicator:** Press the **▼/▲ Up/Down button** to select this feature. The level gauge (volume based) and hour glass (time based) icon is a visual representation of the amount of acid (pH Settings) or chlorine (OPR Settings) available in the container. Press **◀/▶** six times to fill the gauge (container full). The indicator displays six horizontal bars when full. The level gauge is not available if the doser is unable to determine the pump dispense rate, the supply volume, or if there is no supply “reminder” set up (see page 12). The gauge is displayed as an “hour glass” if the supply is based on time rather than volume (see page 6)

**Limit [Clear]:** Press the **▼/▲** to select this feature. Press the **◀/▶** to clear the current dosage limit timer. After pressing the button, “CLEARED” is displayed, indicating that the current dosage limit is cleared.

## IntelliChem System Power Up Screens

IntelliChem  
v1.010 01/12/11  
Pentair Water  
Pool and Spa

**Power-up Sequence:** During power-up IntelliChem displays the initialization screens before the main status screen is displayed. During this initial power up sequence, IntelliChem performs an internal self test and continues with a system calibration. The first screen includes the current software version and date.

AUTO CALIBRATION

AUTO CALIBRATION is displayed each time IntelliChem is powered up.

AUTO CALIBRATION  
pH 6.35 7.65 OK  
ORP 738 398 OK  
\*\*\*PASSED\*\*\*

In the next auto-calibration sequence the pH and ORP meters are tested with on-board circuitry and calibrated to the built-in reference devices. An out-of-tolerance condition is immediately reported as an error so the user can have the unit serviced.

IntelliChem Auto  
Setup Wizard  
Press MENU to go  
to each new step

The very first time IntelliChem is powered up and after a factory reset, the **Auto Setup Wizard** start screen is displayed. Otherwise access the wizard from the main menu (see page 6).

Awaiting  
POWER&FLOW DELAY  
H:00 M:14 S:18  
please wait...

The normal start up screen will simply be this one, awaiting Power On & Flow Delay. The countdown timer shows the remaining time before the unit starts reading the probes and controlling the doser.

pH OK 7.46  
Mixing 00:07:03  
ORP OK 450  
Mixing 00:07:54

**Main Status Screen:** After IntelliChem has completed the auto configuration (for auto setup screens, see page 6) the main status screen displays the measurements of the connected pH and ORP sensors.

## Set Password Protect

The password protect feature prevents access to certain menus and prohibits all menu changes and manual feeds. For more information, see Set Password on page 18.

To set the password protect:

Set Password  
PW [1234]  
Lock [Off ]

Locked - Please enter  
password  
> 1234

1. Press MENU ▼/▲ Configuration ► and ▼/▲ Set Password.
2. **Set Password (PW):** Press the ▼/▲ **Up/Down arrow button** to select the first password digit (0-9).
3. Press the ◀/▶ **Right/Left arrow button** to move the cursor to the next digit.
4. Press the ▼/▲ **Up/Down arrow button** to select the second password digit. Repeat steps 3 and 4 for the third and fourth password digit.
5. Press the ▶ **Right arrow button** to move the cursor to the **Lock Menu** setting.
6. Press the ▼/▲ **Up/Down arrow button** to select **OFF**: Do not enable control panel button lockout. **ALL**: Lockout MENU, pH Settings and ORP Settings buttons). Tank Levels cannot be changed. **MENU**: Lockout MENU button (not pH Settings and ORP Settings buttons). Setpoints or Sat Index values TA, CYA, CH cannot be changed.
7. To exit, press the MENU button (press three times to return to the main screen).

Note: Entering the password 0000, allows you to enter a protected screen by pressing MENU. Also, once the password is entered, access is granted for the duration specified by the Menu timeout setting in the Configuration/Display Mode menu (see page 17).

## Password Protect and IntelliTouch, EasyTouch and SunTouch Automation Control Systems

**Note: If the password lock is enabled from IntelliChem it will also be locked out on the IntelliTouch, EasyTouch or SunTouch automation control system.**

When IntelliChem is controlled by the IntelliTouch, EasyTouch or SunTouch automation control system, if the password is set and locked on the IntelliChem, **it cannot be changed** from the automation control panel. **To change** a "LOCKED" password from the automation system, enter the password on the IntelliChem, it will remain active for the Menu Timeout MM:SS period. During that time, the automation system will be able to set the appropriate settings, just as you would from the IntelliChem front panel. Receiving updated settings from automation will continue to extend the Menu Timeout, just as if you're accessing the menu on the IntelliChem itself.

## Display Modes

IntelliChem main status screen can be setup to display basic or advanced system information. To setup the Display Mode, see “Configuration” menu on page 17. The **Basic** display mode shows the current pH and ORP measurements including a message describing any existing pH (line two) and ORP (line four) alarms. The **Advanced** display mode shows all the current measurements and alarm messages as well as dose and mix timers showing the progress of those processes.

### Basic display mode

pH >OK 7.4  
-.72 Scaling  
ORP OK 730  
Monitoring

The Basic mode displays the current pH and ORP measurements (pH in 10th and ORP in 5mV) with any alarms and tank levels if enabled.  
Note: Alarms are displayed on all Basic and Advanced modes. > or < is displayed as soon as values exceeds alarm trip point is replaced with “HIGH/LOW” after the specific Alarm Delay.

### Advanced display mode

pH HIGH 7.91  
pH Dose Limit  
ORP OK 683  
Mixing 00:07:54

Displays three different Alarms. The example screen shows: FEEDING, MIXING, & HOUR GLASS TIMER ALARMS. (These can co-exist). NO FLOW.  
The advanced mode displays the current pH and ORP high precision measurements (extra digit. e.g (pH=100th - ORP=1mV resolution), alarms, tank levels, process messages, timers.

### Basic and Advanced Display with Error Messages

NO FLOW DETECTED  
Check pump, flow  
Cell, filter,  
and valves.

If IntelliChem detects the pool water circulation pump is not active, a NO FLOW message is displayed. ORP and pH values are not measured when there is no flow, and therefore not displayed.

## Auto Setup

Use the Auto Setup feature for first-time setup or standard configurations. Follow the on-screen prompts and enter information about your system configuration (pH/ORP internal or external pumps, pool size, filter time, chemical container size and gallons per day feed time etc.). IntelliChem uses this information to automatically setup reminder times, calculate feed times, proportional limits and alarms. The following describes the Auto Setup screen. Press the **MENU button** to access the Auto Setup menu. To change a menu setting or value press the **▼/▲ Up/Down arrow button**. Press the MENU button to save each selection.

Press **MENU ▼/▲ Auto Setup ►**

**Previous Values:** Use to recalculate new dose times etc., if no custom settings exist. Not recommended for custom settings; use the menu directly to make these changes.

**Reset All:** Use to make major configuration changes.


IntelliChem Auto  
Setup Wizard  
Press MENU to go  
to each new step


To exit  
Auto  
Setup,  
press ◀

Dosing will  
resume when you  
exit this menu  
Press any button ▶

Would you  
like to use  
previous values?  
[Yes | Reset All]

shows t





## IntelliChem System Default Values

### pH

pH Set Point:	7.5
pH Alarm High:	7.8
pH Alarm Low:	6.8
pH Alarm Delays:	5 min. for both
Sensitivity:	Low

### OPR

ORP Set Point:	700
ORP Alarm High:	750
ORP Alarm Low:	650
ORP Alarm Delays:	5 min. for both
Sensitivity:	Low
pH Lockout:	7.8

### Miscellaneous Default Values

Display Mode:	Basic
Control Panel LED Brightness:	10%
Menu Timer:	M:02 S:30
Menu Backlight Timer:	M:00 M:20
Power-On Delay:	14 minutes
Flow Switch Delay:	1 minute
Dose Priority:	Simultaneous dosing
Password 1234 - Lock = Off	

## MENUS

<b>MAIN SCREEN</b>	
<b>PH MENU</b> (page 11)	<p><b>pH Dosage</b> (Page 1/2) <b>Dosage (For liquid; Volume/Time):</b>  <b>(For CO<sub>2</sub>; Time or to set point):</b> Mixing Time: H:24 M:59  <b>pH Dose by Volume</b> (Page 2/2) Dose: [0-9999], Limit: [0-64350],  Units: [oz/ml], Clear [Manual]  <b>pH Dose by Time</b> (Page 2/2) Dose: [00:00:00], Limit: [00:00:00], Clear: [Power-On]  <b>pH Dose to Setpoint</b> (Page 2/2) Limit: [00:00:00], Clear: [24hr Flow]  <b>pH Setpt:</b> 7.5 (use Left/Right button to adjust pH set point)  <b>pH Tweak</b> - reading = 7.xx tweak: 0.0 (+/- 0.3)  <b>pH Supply</b> (Page 1/2) <b>Units:</b> gal-US/gal-UK/Liters/Time, <b>Chemical:</b> [Acid, pH-, Base, pH+] -  Page 2/2 - <b>Capacity:</b> 0.000-200.00 gal-US/galUK/Liters - <b>Gauge:</b> Egg timer or tank gauge -  Page 2/2 <b>Time:</b> Reminder in: H:100 M:00  <b>Sensitivity:</b> - [Low/High/Off] - Full Dose at 0.5pH (Low - Liquid, CO<sub>2</sub>),  (High 0.2pH from set point).  <b>pH Alarms:</b> Page1/2 High 7.8 - Delay 00:05:00 - Page 2/2 Low: 6.8 Delay 00:05:00</p>
<b>ORP MENU</b> (page 14)	<p><b>ORP Dosage</b> (Page 1/2) <b>Dosage (For liquid; Volume/Time):</b>  <b>(For SCG; Time or to set point):</b> Mixing Time: H:24 M:59  <b>ORP Dose by Volume</b> (Page 2/2) Dose: [0-9999], Limit: [0-64350], Units: [oz/ml], Clear [Manual]  <b>ORP Dose by Time</b> (Page 2/2) Dose: [00:00:00], Limit: [00:00:00], Clear: [Power-On]  <b>ORP Dose to Setpoint</b> (Page 2/2) Limit: [00:00:00], Clear: [24hr Flow]  <b>ORP Setpt:</b> 700 (use Left/Right button to adjust ORP set point)  <b>ORP Tweak</b> - reading = xxx tweak: 0.0 (+/- 50mV)  <b>ORP Supply</b> (Page 1/2) <b>Units:</b> gal-US/gal-UK/Liters/Time, <b>Chemical:</b> [Chlorine/Bromine] -  Page 2/2 - <b>Capacity:</b> 0.000-200.00 gal-US/galUK/Liters - <b>Gauge:</b> Egg timer or tank gauge -  <b>Gauge: Egg Timer or tank gauge</b> - Page 2/2 Time: Reminder in: H:100 M:00  <b>Sensitivity:</b> - [Low/High/Off] - Full Dose at 50 mV ORP (Low - Liquid),  (High 20 mV from set point, Off (IntelliChlor OFF)  <b>ORP Alarms:</b> Page1/2 High 750 - Delay 01:00:00 - Page 2/2 Low: 650 Delay 02:00:00</p>
<b>CONFIGURATION</b> (page 17)	<p><b>Pool Details:</b> Volume: 0.2K-230K (200-230,000 Liters max) Units:  Gal US (gal-US/gal-UK/Liters), Daily Hrs/Mins  <b>Display Mode:</b> Display Mode: Basic/Advanced, Brightness Front LEDs: (0-100%),  Menu/BkLt Hrs/Mins. (24 hrs -30sec.)  <b>Delays:</b> Power-on: 1-60 mins. (15min default) - FlowSwitch: 1-60 mins. (1 min default) -  Doser/Probe: Seconds 0,15,30,60secs.  <b>Set Password:</b> PW [1234] - Lock [OFF/MENU/ALL]  <b>Preferences:</b> pH Lockout: 7.8, Integration: 32. <b>Probe Check:</b> [No/Yes]  <b>Dose Priority:</b> [Simultaneous pH Priority]  <b>Diagnostics:</b> Software Rev, Meter Test {Auto Calibration},  Probe Test (Open Probe Test) Timers,  Chlorinator, Status Codes, Factory Reset, Self Test Sequence  <b>Hardware:</b> pH Control: 1/2 Doser Type [Internal Pump, External/Relay,  CO<sub>2</sub> Ext/Relay, None] - pH Control 2/2 Flow: xx GPD <b>See page 18 for details</b></p>
<b>SAT INDEX</b>	<p><b>See page 24 for details</b> - pH: 7.5 - Temp: 00°F -  - CH: xxx - TDS: xxx - TA:xx = CYA: xx Recalc/Tab:</p>
<b>AUTO SETUP</b>	<p><b>See page 6 for details</b></p>
<b>HELP GUIDE</b>	<p>Help Guide, Meter Test, Probe Test, Clear Tweaks,  Clear Probes, Check Dosers, Chemicals, SAT Index, Balance Water,  Replace Probes, Repeat</p>

## Navigating IntelliChem Menus

The following examples show how to navigate the main menu and sub-menus. Press the **MENU button** to access the main menu. Press the **▶ Right arrow button** to select a menu item and select items in a sub-menu. Press **◀/▶** to select previous/next item on a page. To change a menu setting or value press the **▼/▲ Up/Down arrow button**. Press the MENU button to exit and return to the previous menu items. Note: Settings are automatically save when changed.

Example: To change the pH dosage settings (pH Dosage screens 1/2 and 2/2):

Press **MENU ▼/▲ pH Menu ▶ pH Dosage ▶**

▶ pH Menu ▲  
ORP Menu  
Saturatn Index  
Configuration ▼

ORP Menu ▲  
Saturatn Index  
Configuration  
Auto Setup ▼

▶ pH Dosage  
pH Setpt: 7.5  
pH Tweak  
pH Supplies

pH Dosage 1/2  
Dose: by Volume  
Mixing Time:  
H:00 M:59

pH Dosage 2/2  
Dose Limit Units  
3 21 [oz]  
Clear [Power-On]

pH Dosage 1/2  
Dose: by Volume  
Mixing Time:  
H:09 M:59

▶ pH Menu ▲  
ORP Menu  
Configuration  
Auto Setup ▼

pH OK 7.46  
Mixing 00:07:03  
ORP OK 450  
Mixing 00:07:54

1. Press the **▼/▲ Up/Down arrow button** to scroll through the main menu items. For this example choose pH menu.
2. Press the **▶ Right arrow button** to select the pH menu.
3. Press **▶ arrow button** to select pH Dosage (page 1 of 2). Press **▼/▲** to toggle between pH Dosage page 1/2 and page 2/2.
4. From pH Dosage page 1/2, press the **▶** to select Dose (feed method). To change the feed method press **▼/▲** to change the selection: “by Volume” or “by Time”.
5. Press the **▶** to select the next item. The cursor moves down to the “Mixing Time” hours setting (H:00).
6. Press the **▼/▲** to adjust the Mixing Time hours between feeding acid. Press **▶** to select the minutes. Press **▼/▲** to adjust the minutes. After adjustment, the display shows the new setting. Note: Press either **◀/▶** button to scroll forward or backwards within this sub-menu.
7. Select **1/2** page indicator. Press the **▼/▲** buttons to select the next pH Dosage screen (**2/2**).
8. Use **◀/▶** buttons and **▼/▲** buttons to select and changes the “Dose” (amount of liquid dispensed before waiting for a mix time), Limit (amount of liquid dispensed in one day Units (apply to dose and limit, power cycle, 24 Hr. period, or requiring manual intervention, and Clear settings displayed on the page 2/2).
9. Press the **MENU** to return to the previous pH Dosage page 1/2 menu items.
10. Press the **MENU** again to exit pH Dosage menu.  
Note: All settings are immediately save when changed.

## Menu Description

### pH Menu

►pH Menu ▲  
 ORP Menu  
 Saturatn Index  
 Configuration

►pH Dosage ▲  
 pH Setpt: 7.2  
 pH Tweak  
 pH Supplies ▼

pH Dosage 1/2  
 Dose: by Time  
 Mixing Time:  
 H:00 M26

#### by Volume

pH Dosage 2/2  
 Dose Limit Units  
 1200 64100 [mL]  
 Clear [Manual]

#### by Time

pH Dosage 2/2  
 Dose 00:33:45  
 Limit 04:14:00  
 Clear [Power-On]

#### by Setpoint

pH Dosage 2/2  
 Dose to Setpoint  
 Limit 00:08:00  
 Clear [24hr ]

**To access the pH Menu:** Press **MENU** ► **pH Menu** ► **pH Dosage** - The pH Dosage screen 1/2 displays the current dose method (by Volume, Time or to Setpoint).

### pH Dosage (for Internal and External Pumps)

#### pH Dosage (page 1/2)

**Mixing Time:** Select the amount of time in hours and minutes that IntelliChem will wait in between pH feeding. It should be set to allow sufficient mixing time for the chemicals to become distributed throughout the pool. The pH Mixing Time is set by Auto Setup.

**Dose (by Volume/Time):** Choose the feed method: “by Volume” and “by Time” are available choices for liquid dosers, as determined by the hardware setup. If CO<sub>2</sub> is selected, then the available choices are “by Time” and “To Setpoint”.

#### pH Dosage (page 2/2)

**Dose (Volume):** Displays the current dose size (0-9999) in ounces [oz] or milliliters [ml]. Set the amount of ounces (or milliliters) that IntelliChem will feed pH (acid) each time IntelliChem calls for pH chemicals. The Dose (Volume) is set by Auto Setup wizard based on pool volume and filter run time.

**Dose (Time/Setpoint):** Displays the current pH dose (feed) time. Sets the amount of time in hours, minutes and seconds that IntelliChem will feed pH (acid) each time IntelliChem calls for pH chemicals. The pH dose time is set by Auto Setup. The Dose (Time) is set by Auto Setup wizard based on pool volume and filter run time. Dose (to Setpoint) does not have a dose amount, only a time limit.

**Limit (Time/Volume):** Displays the current feed limit. Sets the maximum amount of time/volume in hours, minutes and seconds or volumetric units that will be allowed to feed pH chemicals. As a safety feature, the IntelliChem will only allow a certain amount of pH chemicals to feed into the system in a 24 hour period. Set the maximum amount of time in hours (0-24) that will be allowed to feed. IntelliChem tracks each dose time, and adds them together. When the maximum dose time is reached or exceeded, the ORP feed system is prevented from feeding until the next 24 hour period begins, or when the feed timers are cleared manually. The default pH Limit is based on a safe limit of 2 ppm of the size of the pool, up to a 5 oz maximum. The Limit (Time/Volume) is set by Auto Setup wizard based on pool volume and filter run time.

*Continue on next page.*

## pH Menu (Continued)

### pH Dosage (page 2/2) *Continue*

**Clear:** Select **Power-On** to clear the pH dose limit time when IntelliChem is powered on. Select **Manual** to manually clear the pH dose limit timers and select **24 Hrs** to clear timers automatically each 24 hour period of continuous operation.

To protect the pool water, IntelliChem will automatically shutdown pH and ORP feed control and display an alarm message if IntelliChem (or any other dispensing device) runs non-stop for more than the selected Limit time or volume. This prevents IntelliChem from non-stop feeding pH reducer, because of a sensor error or external problem with the pool. This allows you to evaluate the pool chemistry before continuing with pH feeding.

### pH Set Point

Displays the current pH set point value. Adjust the pH set point to meet pool and spa chemistry standards. The adjustable range is from 7.2 to 7.6 in increments of 0.1. The default pH set point value is 7.5.

To adjust the acid feed pH set point: Press **MENU pH Menu ▶▼pHSetpt**  
**Press ◀/▶ to decrease or increase the current pH set point value.**

Note: When using CO2, parameters are the same as above.

### pH Tweak

The exact reading of each individual pH sensor can vary because of water makeup and variances in probe condition age, etc. The pH Tweak menu feature allows you to adjust the pH sensor reading to match the manual reading taken. The adjustable range is **+/- 0.3**. After adjusting the pH value, the main screen should now display the same value as the manual reading.

To adjust the pH sensor level:

Press **MENU ▼/▲ pH Menu ▶ pH Tweak**

The current value is displayed (reading = x.xx). Press **▼/▲** to adjust the pH sensor level (+/- 0.3). To remove the tweak, set the level back to 0 (zero).

### pH Supplies

#### pH Supply (page 1/2)

**Units:** Select gal-US, gal-UK, Liters or Time (hours/minutes)\*.

**Chemical:** Use Acid, (pH -) or Base (pH+).

<p><b>pH Supply</b> 1/2  <b>Unit:</b> USGal  <b>Chemical:</b>  <b>[Acid, pH-]</b></p>
---

<p><b>pH Supply</b> 2/2  <b>Capacity:</b>l  <b>4.00 USGal</b>  <b>Gauge:</b></p>
--

<p><b>pH Supply</b> 2/2  <b>Reminder in:</b>  <b>Hours:</b>  <b>Minutes: 59</b> ⌘ <b>6</b></p>
--

## pH Menu (Continued)

### pH Supply (page 2/2)

**Capacity:** Select from 0 to 200 maximum gal-US, gal-UK, or Liters.

**\*Time (Reminder in: H:xxx M:xx)** If the supply Units were set to Time, the Capacity feature becomes a Reminder feature, as in an egg-timer. This can be used to trigger an alarm, based on cumulative feed times as to when to check the CO2 cylinder. Set the reminder time in hours (0-8760) and minutes (00-59) on ORP Supply page 2/2. Note: Entering the hours and minutes time (H:00 M:00) will display the hour glass icon on the main screen.

**Level Gauge (liquid only):** Displays level gauge when using liquid chemical doser. Tank icon symbol is used for liquid chemical configurations that include valid supply and doser feed rate information.

### pH Sensitivity

IntelliChem can adjust the feed times for pH depending on how close the current reading is to the set point. This helps to prevent overshooting and makes it easier for IntelliChem to reach the exact set point.

Low= (default) Full dose at 0.5 pH above setpoint

High= Full dose at 0.2 pH above setpoint

Off= Full dose at 0.005 pH above setpoint

For example: When set to LOW (full dose at 0.5 above setpoint), if pH setpoint is 7.2 and pH reading is 7.7 or above, a full dose amount is dispensed. As the pH comes closer to setpoint, say 7.45 (0.25 above setpoint - or- half the 0.5 pH value), the dispensed amount will be 1/2 of the specified dosage. And, at 0.05 (1/10th of 0.5 value) above setpoint (7.25), the dosage will be 10% of that specified in the dosage menu. In that case, if the dosage was specified to be 10 ounces, IntelliChem will dispense only 1 ounce at a time. This can be confusing to someone who is watching the IntelliChem because it will appear to not be dosing the full amount; therefore, in the Advanced display mode, the process timer will be shown as "%Dosing 0.1 oz", the "%" indicating that the dosage is reduced due to this Sensitivity feature.

To set the pH Sensitivity level: **Press MENU - pH Menu ▼/▲ pH Sensitivity ►**

### pH Alarms

IntelliChem automatically displays a screen message indicating the pH level has reached or exceeded the **HIGH (7.8) or LOW (6.8)** pH alarm level settings.

IntelliChem will automatically set a high and low alarm for the pH level. The Delay time is the amount of time between the detected alarm condition and when IntelliChem displays the alarm message on the main screen. The Delay setting is adjusted in increments of 15 seconds.

To set the pH alarm "High" level and "Delay" time (page 1/2):

Press **MENU pH Menu ► pH Alarms ► ▼/▲ pH Alarms ► ▼/▲ (page 1/2 is High Level Alarm, page 2/2 is Low Level Alarm)**

Press **►** to select the alarm, High level and Delay Time (00:50:00).

To set the pH alarm "Low" level and "Delay" time (page 2/2):

Press **MENU ▼/▲ pH Menu ► pH Alarms ▼/▲ Low / Delay (2/2)**

Press **▼/▲** to change pH alarms Low level and Delay Time (00:05:00).

## ORP Menu

### ORP Dosage (dispense chlorine or bromine)

<p>pH Menu          ▶ORP Menu          Saturatn Index          Configuration</p>	<p>▶OPR Dosage ▲          OPR Setpt: 700          OPR Tweak          OPR Supply ▼</p>	<p>ORP Dosage 1/2          Dose: by Time          Mixing Time:          H:00 M26</p>
<p><b>by Volume</b></p> <p>ORPDosage 2/2          Dose Limit Units          1200 64100 [mL]          Clear [Manual]</p>	<p><b>by Time</b></p> <p>ORPDosage 2/2          Dose 00:33:45          Limit 04:14:00          Clear [Power-On]</p>	<p><b>by Setpoint</b></p> <p>ORPDosage 2/2          Dose to Setpoint          Limit 00:08:00          Clear [24hr ]</p>

**To access the ORP Menu:** Press **MENU** ▶ **ORP Menu** ▶ **ORP Dosage** - The ORP Dosage screen 1/2 displays the current dose method (by Time or to Setpoint).

### ORP Dosage (for Internal and External Pumps)

#### ORP Dosage (page 1/2)

**Mixing Time:** Select the amount of time in hours and minutes that IntelliChem will wait in between ORP dosing. It should be set to allow sufficient mixing time for the chemicals to become distributed throughout the pool. The ORP Mixing Time is set by Auto Setup.

**Dose (by Volume/Time):** Choose the feed method: “by Volume” and “by Time” are available choices for liquid dosers, as determined by the hardware setup. If IntelliChlor (SCG) is selected, then the available choices are “by Time” and “To Setpoint”.

#### ORP Dosage (page 2/2)

**Dose (Volume):** Displays the current dose size (0-9999) in ounces [oz] or milliliters [ml]. Set the amount of ounces (or milliliters) that IntelliChem will dose ORP (chlorine/bromine) each time IntelliChem calls for ORP chemicals. The Dose (Volume) is set by Auto Setup wizard based on pool volume and filter run time.

**Dose (Time/Setpoint):** Displays the current ORP dose (feed) time. Sets the amount of time in hours, minutes and seconds that IntelliChem will feed ORP (chlorine/bromine) each time IntelliChem calls for ORP chemicals. The ORP dose time is set by Auto Setup. The Dose (Time) is set by Auto Setup wizard based on pool volume and filter run time. Dose (to Setpoint) does not have a dose amount, only a time limit.

**Limit (Time/Volume):** Displays the current feed limit. Sets the maximum amount of time/volume in hours, minutes and seconds or volumetric units that will be allowed to feed ORP chemicals. As a safety feature, the IntelliChem will only allow a certain amount of ORP chemicals to feed into the system in a 24 hour period. Set the maximum amount of time in hours (0-24) that will be allowed to feed. IntelliChem tracks each dose time, and adds them together. When the maximum dose time is reached or exceeded, the ORP feed system is prevented from feeding until the next 24 hour period begins, or when the feed timers are cleared manually. The default ORP Limit is based on a safe limit of 2 ppm of the size of the pool, up to a 5 oz maximum. The Limit (Time/Volume) is set by Auto Setup wizard based on pool volume and filter run time.

**Clear:** Select **Power-On** to clear the ORP dose limit time when IntelliChem is powered on. Select **Manual** to manually clear the ORP dose limit timers and select **24 Hrs** to clear timers automatically each 24 hour period of continuous operation.

## ORP Menu (Continued)

### ORP Set Point

Displays the current ORP set point value. Adjust the ORP set point to meet pool and spa chemistry standards. The adjustable range is from 650 to 800 in increments of 10. The default ORP set point value is 700.

To adjust the ORP set point: Press **MENU ORP Menu ►▼ORP Setpt**  
**Press ◀/▶ to decrease or increase the current ORP set point value.**

Note: When using IntelliChlor SCG, parameters are the same as above.

### ORP Tweak

The exact reading of each individual OPR sensor can vary because of water makeup and variances in probe condition age, etc. The OPR Tweak menu feature allows you to adjust the OPR sensor reading to match the manual reading taken. The adjustable range is **+/-50mV**. After adjusting the OPR value, the main screen should now display the same value as the manual reading.

To adjust the ORP sensor level:

Press **MENU ▼/▲ pH Menu ► ORP Tweak**

The current value is displayed (reading = x.xx). Press **▼/▲** to adjust the ORP sensor level (+/- 50 mV). To remove the tweak, set the level back to 0 (zero).

### ORP Supplies

#### ORP Supply (page 1/2)

**Units:** Select gal-US, gal-UK, Liters or Time (hours/minutes)\*.

**Chemical:** Use Chlorine or Bromine.

ORP Supply 1/2 Unit: USGal Chemical: [Chlorine]	ORP Supply 2/2 Capacity:l 200.25 USGal Gauge:
	ORPSupply 2/2 Reminder in: Hours: Minutes: 59 ⌘ 6

#### ORP Supply (page 2/2)

**Capacity:** Select from 0 to 200 maximum gal-US, gal-UK, or Liters.

**\*Time (Reminder in: H:xxx M:xx)** If the supply Units were set to Time, the Capacity feature becomes a Reminder feature, as in an egg-timer. This can be used to trigger an alarm, based on cumulative feed times as to when to clean the SCG plates. Set the reminder time in hours (0-8760) and minutes (00-59) on ORP Supply page 2/2. Note: Entering the hours and minutes time (H:00 M:00) will display the hour glass icon on the main screen.

**Level Gauge (liquid only):** Displays level gauge hour when using liquid chemical doser. Tank icon symbol is used for liquid chemical configurations that include valid supply and doser feed rate information.

## ORP Menu (Continued)

### ORP Sensitivity

IntelliChem can adjust the feed times for ORP depending on how close the current reading is to the set point. This helps to prevent overshooting and makes it easier for IntelliChem to reach the exact set point.

**Low**= (default) Full dose at 50mV below setpoint

**High**= Full dose at 20mV below setpoint

**Off**= Full dose at 1mV below setpoint

For example: When set to LOW (full dose at 50mV below setpoint), if ORP setpoint is 700 and ORP reading is 650 or below, a full dose amount is dispensed. As the ORP comes closer to setpoint, say 675mV (25mV below setpoint - or- half the 50mV value), the dispensed amount will be 1/2 of the specified dosage. And, at 695 (1/10th of 50mV value) below setpoint (700), the dosage will be 10% of that specified in the dosage menu. In that case, if the dosage was specified to be 10 ounces, IntelliChem will dispense only 1 ounce at a time. This can be confusing to someone who is watching the IntelliChem because it will appear to not be dosing the full amount; therefore, in the Advanced display mode, the process timer will be shown as "%Dosing 0.1 oz", the "%" indicating that the dosage is reduced due to this Sensitivity feature.

To set the ORP Sensitivity level: **Press** MENU - ORP Menu ▼/▲ ORP Sensitivity ►

### ORP Alarms

IntelliChem automatically displays a screen message indicating the ORP level has reached or exceeded the **HIGH (750 mV) or LOW (650 mV)** pH alarm level settings. IntelliChem will automatically set a high and low alarm for the ORP level. The Delay time is the amount of time between the detected alarm condition and when IntelliChem displays the alarm message on the main screen. The Delay setting is adjusted in increments of 15 seconds.

To set the ORP alarm "High" level and "Delay" time (page 1/2):

**Press** MENU ORP Menu ► ORP Alarms ► ▼/▲ ORP Alarms ► ▼/▲  
(page 1/2 is High Level Alarm, page 2/2 is Low Level Alarm)

Press ► to select the alarm, High level and Delay Time (00:50:00).

To set the ORP alarm "Low" level and "Delay" time (page 2/2):

**Press** MENU ▼/▲ ORP Menu ► ORP Alarms ▼/▲ Low / Delay (2/2)

Press ▼/▲ to change ORP alarms Low level and Delay Time (00:05:00).

## Configuration Menu

### Pool Details

From this menu, you can set your pool size, units to display and the daily run time which should match your daily pool pump filtration time.

**Volume:** Pool volume (size). Select range is 200 - 230,000 gal (gal-US, gal-UK and Liters).

**Units:** Select units to display in English (gal-US), (gal-UK) and Metric Liters.

**Daily:** This daily run time is used for calculating dose and mix times. It is set and used in the Auto Setup script and should be the amount of time the pool pump/filter runs each day.

To access the Pool Details menu:

Press **MENU ▼ Configuration ► Pool Details ►**

### Display Modes

**Mode:** Selects which display mode is displayed: **Basic or Advanced**, Basic mode displays the current pH and ORP levels with any alarms and fuel gauge if enabled. Advanced mode displays high resolution pH and ORP levels and process messages, timers (see page 6).

**LEDs:** Adjusts the brightness level (0-100%) of the front panel LEDs.

**Menu:** Adjusts the amount of time (minutes/seconds) the menu will be on each time the control panel is activated and also the time the entered password is valid.

**BkLt:** Adjusts the amount of time (hours/minutes) the controller screen backlight will be on each time the control panel is activated.

To access the display mode menu: Press **MENU ▼ Configuration ►▼Display ►**

Press **▼/▲** to adjust display settings.

### Delays (minutes)

**Power-On:** Sets the delay time from power up to the first display screen reading. The adjustable time is from 1 to 60 minutes. The default power on time is 14 minutes

**Flow Switch:** Sets the delay time from when the Flow Switch is active to the first display screen reading. The adjustable time is from 1 to 60 minutes. The default flow switch delay time is one minute.

**Doser/Probe:** Sets the delay time from when the Doser turns on to when it takes the next probe measurement. Adjustable time is 0 to 60 seconds. Default is 15 seconds. Use longer times to prevent interaction of doser from affecting the measurement.

To access the delays menu: Press **MENU ▼ Configuration ►▼ Delays ►**

Press **▼/▲** to set the delay settings.

## Configuration Menu (Continued)

### Set Password

IntelliChem menus, the pH button and ORP button on the control panel can be password protected. Once a password has been set, IntelliChem will not allow access to the menu system and no changes to be made without entering the password. For more information see page 5.

**PW:** Enter a four digit password [0000]. Each digit can be assigned 0-9.

**Lock:** Select OFF, MENU (password protect the main menu) or ALL (password protect all control panel buttons). Once the password is entered, access is granted for the duration specified by the Menu timeout setting in the Configuration/Display Mode menu. If the menus are locked, changes via the automation interface will also be locked out.

To access the password menu:

Press **MENU ▼ Configuration ▶ ▼ Set Password ▶**

Press **▼/▲** to select the digit and **◀/▶** move to next digit. Note: If you forget the password, first try the default password 1234, then call Customer Support for assistance.

### Preferences (1/2)

To access the delays menu: Press **MENU ▼/▲ Configuration ▶ ▼ Preferences ▶**  
Press **▼/▲** to adjust the following settings.

<b>Preferences 1/2</b> <b>pH Lockout: 7.8</b> <b>Integration: 32</b> <b>Probe Check: No</b>
--

**pH Lockout:** is the pH reading at which IntelliChem will no longer dose sanitizer (Chlorine/Bromine). Above pH of 7.8 it is generally understood that the ORP reading is suppressed and therefore will not be used to administer additional sanitizer. Just bringing the pH level down will raise the available chlorine and the effective ORP. At this trip point, an alarm message will be shown on the screen and ORP doses will cease. Range is 7.7 to 8.2, default is 7.8.

**Integration:** Is the averaging or smoothing of the instantaneous pH and ORP readings. Range is from 1 to 128 seconds, default is 32 seconds. Too short of a value can result in readings that fluctuate too rapidly. Too high of a value results in a slow and sluggish response. Recommended settings are 32 or 64 seconds for systems in an electrically noisy environment near pumps or static charges. Use shorter setting like 16 or 8 for small spas requiring fast response to dosed chemicals.

**Probe Check:** Enables the Open Probe Test which can determine if the pH and ORP sensor probes are disconnected or non-functional. Although it will not help determine if probes need cleaning, it will catch many types of conditions including bad wiring, disconnected cable, and open/broken probe sensor. If enabled, this feature tests the probes before starting each dose. This validates that the readings used to determine that the dose is required were accurate. If disabled, the probes should periodically be tested with the Configuration/Diagnostics/Probe Test menu item. Check all connections and replace the probes and cables if necessary.

## Configuration Menu (Continued)

### Preferences (2/2)

Preferences 2/2  
 Saturation Index  
 Alarm: +/- 0.3  
 Delay: 00:30:0

#### Saturation Index

**Alarm: +/- 0.3:** If the Saturation Index (SI) level is in the “Corrosive” or “Scaling” range, this feature allows you to enter a Saturation Index (SI) alarm threshold value between +/- 0.1 to +/- 0.9 (+/- 3 default). Select “Disabled” to disable the Alarm feature.

**Delay:** The Alarm Delay feature sets the delay time before the SI Alarm (see above) message is displayed. Enter the delay time from 00:15:00 to 24:00:00 (30 minutes default). Note: Once the SI has passed the threshold for the delay period, an alarm message is displayed showing the Saturation Index Alarm (along with other pH alarms) that includes the value and description.

pH >OK 7.44  
 -.72 Corrosive  
 ORP OK 730  
 Monitoring

pH >OK 7.44  
 +.32 Scaling  
 ORP OK 730  
 Monitoring

These alarm messages are also displayed on the IntelliTouch, EasyTouch and SunTouch control panel.

### Dose Priority

To access the delays menu: **Press MENU ▼/▲ Configuration ►▼Dose Priority ►**  
 Press ▼/▲ to select option.

**Dose Priority:** pH Priority or Simultaneous.

Depending on how the IntelliChem chemical dosers are plumbed and how much water is circulating in the system where the chemicals are injected into the water stream, it may be preferred to only feed Chlorine when Acid is not feeding. This would be the pH Priority setting.

- " Simultaneous allows both chemicals to feed at the same time - and can be used when both feed systems are not liquid chemicals or the injectors are separated by a safe distance in the water stream. **DANGER:** Combining liquid acid and chlorine can result in the formation of hazardous and explosive gas.
- " pH Priority will always feed acid first, and only during the acid mix time or general monitoring period will the IntelliChem feed the liquid chlorine sanitizer. If while feeding chlorine, the pH rises above setpoint, the ORP dose will be stopped and allow acid to feed.

## Configuration Menu (Continued)

### Diagnostics

---

**Software Rev:** Displays the software revision.

**Meter Test:** Performs an internal self-test of the pH/ORP meter and sensing circuitry. Ensures both circuits are performing properly First tests the High circuit in the uncalibrated state, waits for a button press, then tests the Low circuit and waits for a button press. Once these two tests complete, it proceeds with the self-calibration. A Pass or Fail message is displayed. If this test fails, disconnect power and check for water or dirt on the circuit board. Use a can of dry compressed air to clean the board if necessary. If the test continues to fail, contact technical support.

**Probe Test:** This test takes approximately 30 seconds. Perform this test with the sensor cables and probes installed. Probes must be clean and in water. Possible results are :

**Both Probes Good**

**pH: Good            ORP:Bad**

**pH: Bad            ORP:Good**

**pH: Bad            ORP:Bad**

**Timers:** This displays the counters used for tracking the cumulating dose volume and/or time used in determining the Dose Limit. It shows

"PCs" PH cumulative dose limit timer in Days HH:MM:SS

"Ocs" ORP cumulative dose limit timer in Days HH:MM:SS

"ml" Milliliters of cumulative dose for Ph and Orp (0-9999) stops at 9999 ml

"Run" the RUN TIME in Days, HH:MM:SS since powered up.

If you need to know much you've dosed during a day, or how long its been running that day, "Times" will have this information. The cumulative times/ml get reset when you clear the dose limits, The Run Time clears on power-up.

## Configuration Menu (Continued)

### Diagnostics (Continued)

**Chlorinator:** This screen displays the current IntelliChlor (SCG) status, salt (ppm) levels and error conditions. The hexadecimal status value is decoded and displayed in the brackets on the bottom line; multiple error conditions are shown by sequencing through the messages.

This display can be used to determine if the SCG is connected and responding to the IntelliChem. If the IntelliChlor is connected, this display may show "Please wait 2-7 minutes for ppm". This indicates the IntelliChlor is responding to initial contact but until water flow and sufficient salt level is reached, the IntelliChlor will not respond with further information like salt ppm and status. Sometimes it is helpful to cycle power on the IntelliChlor and wait 10 minutes for the green lights before it will respond with ppm and status information; it may not respond if the Salt or Cell lights are flashing red.

If the Configuration / Hardware / ORP Control / Doser Type is set to IntelliChlor, the IntelliChem will control the IntelliChlor as it would a doser, actively turning it on (100%) for chlorine demand, and off (0%) when the ORP reaches the desired set point.

For the Chlorinator to work when connected to an Automation controller like the IntelliTouch, EasyTouch, or SunTouch, those units must be configured with the IntelliChlor enabled. The displays is as follows:

```
-----
Chlorinator Info:
Salt: 4500 ppm
Status Code=00H
[OK-NO ERRORS ] V
-----
```

```
To get updated
ppm, cycle SCG
power and wait.
Press any button
-----
```

```
Possible messages are:
No Flow
Low Salt
Very Low Salt
High Current
Clean Cell
Low Voltage
```

## Configuration Menu (Continued)

**Status Codes:** This displays a complex series of values that indicate the real-time status and alarm conditions.

Top line, Codes: HA= is the automation Home Address that IntelliChem has locked onto.

In the upper-right corner,

R0,1,2,4 which represents the UOC comm status.

R0 = standalone (no KA from Automation since power up)

R1 = Found KA packets within 30 seconds of power up

R2 = Found KA packets later, after 30 seconds, so was operating in standalone for a while

R4= Was in Automation mode (sending IntelliChlor commands through IntelliTouch) but has dropped the connection.

The two-digit number (0-99) directly below the R# is the number of seconds it's gone without a valid KA packet. It should generally be 00-04 seconds. More than that means that IntelliChem is missing the automation KA packets.

Note: Status and Alarm hexadecimal displayed codes represent the current IntelliChem status. For further information, contact Technical Support (800) 831-7133.

**Factory Reset:** Clear all calibrated values and run Auto Setup to initialize IntelliChem. For Factory Default Settings.

**Self Test Sequence:** Upon entering a self test sequence, all dosing will pause until the test is completed. Follow the on-screen prompts. "PASSED" indicates the test was successful. See Troubleshooting section for error conditions, on page 46.

## Hardware

Most common hardware configurations can be selected by using the Auto Setup Wizard. This menu allow more complex and custom settings. Use the Hardware menu to configure IntelliChem for the pH and ORP hardware controls and dose being used. Upon entering the hardware setup menu, all dosing will pause until the hardware setup is completed.

After pressing the Hardware button the following message is displayed.

**Dosing will resume when you exit this menu. Press any button**

To access the hardware menu: **Press MENU ▼ Configuration ►▼ Hardware ►**

### **pH Control (page 1/2 - 2/2)**

**Doser Type 1/2:** Select the pH Control Dose Type:

- IntelliChem pH feed method being used (INTERNAL PUMP, EXTERNAL RELAY, CO2 EXT/RELAY (Carbon dioxide tanks), NONE).

**Doser Type 2/2:**

- **INTERNAL PUMP:** Right, MTR\_R, Left, MTR\_L
- **EXTERNAL RELAY:** Ex\_Relay 1, Ex\_Relay 2
- **CO2 EXTERNAL RELAY:** Ex\_Relay 1, Ex\_Relay 2

**Flow (Rate) 2/2:**

- **INTERNAL PUMP (MTR\_R/MTR\_L):** FLOW: xxx GPD (gallons per day) - (53, 65, 75).
- **EXTERNAL RELAY 1 or 2:** RATE: xxx GPD (gallons per day). Note: Set to 0 to use time-based feed instead of volumetric (only on the Ext Relays (not internal motors).
- **CO2 EXTERNAL RELAY 1 or 2:** Use Time (0) or SCFH (1-400).

## Configuration Menu (Continued)

### **ORP Control (page 1/2 - 2/2)**

**Doser Type 1/2:** Select the ORP control hardware:

- IntelliChem ORP feed method being used (INTERNAL PUMP, EXTERNAL RELAY, INTELLICHLOR Salt Chlorine Generator (SCG), NONE).

**Doser Type 2/2:**

- **INTERNAL PUMP:** Right-Side (MTR\_R), Left-Side (MTR\_L)
- **EXTERNAL RELAY:** Ex\_Relay 1, Ex\_Relay 2
- **INTELLICHLOR:** All Models (IC20, IC40, IC60)

**Flow (Rate) 2/2:**

- **INTERNAL PUMP (MTR\_R/MTR\_L):** FLOW: xxx GPD (gallons per day)
- **EXTERNAL RELAY 1 or 2:** RATE: xxx GPD (gallons per day). Note: Set to 0 to use time-based feed instead of volumetric (only on the Ext Relays (not internal motors)).

Hardware settings must be chosen carefully. If both dosers are assigned to the same internal pump or external relay, the program will display an error message upon exiting the Hardware menu.

**Alarm Output** Select the following IntelliChem alarm output information:

- **External alarm output:** Ex\_Relay1 or Ex\_Relay2.

For an external alarm indicator, an unused relay may be selected to turn on when the red Alarm LED on the front panel is turned on.

The alarm relay must be chosen carefully. If Ex\_Relay1 or Ex\_Relay2 is used for a doser, it must not be used for an alarm output. Upon exiting the Hardware menu, the program will check to be sure the same relay is not used more than once. If a relay is assigned to more than one function, an error message will be displayed.

error message:

```

-----
Alarm Relay
conflicts with
Ext Doser Relay
Changed to Ex_R1
----- or
Changed to Ex_R2
or
Changed to N/A

```

## Auto Setup

### Auto Setup

See page 6 for details.

## Sat Index

### Saturation Index

The Saturation Index (SI), also called the Langelier Index, is a chemical equation or formula used to diagnose the water balance in the pool. The Saturation Index formula is **SI = pH + TF + CF + AF - 12.1 (or 12.2 for salt pools)**. To calculate the Saturation Index, you must first test the pool water for pH, temperature, calcium hardness, and total alkalinity. Refer to a chart for assigned values for your temperature, hardness, and alkalinity readings then add these to your pH value. Subtract 12.1 (or 12.2 for salt pools), which is the constant value assigned to Total Dissolved Solids and a resultant number will be produced. A result between +/-0.3 indicates balanced water. Test results not within these values require chemical adjustments to achieve balance. This formula is more or less reliable but not guaranteed. In some cases, individual readings for pH, calcium, and Total-Alkalinity might be beyond normal recommendations, however, combined within the formula can produce "balanced water." The SI is useful to pinpoint potential water balance problems.

To access the Sat Index menu:

Press MENU ▼/▲ Saturatn Index ►

Press ▼/▲ and ◀/▶ to adjust the Saturation Index values.

►pH Menu ▲	pH: 6.0	Temp: 77F
ORP Menu	CH: 250	TDS1000
Saturatn Index	TA: 90	CYA:18
Configuration	SI = -0.9	CORRSV

### Sat Index Menu

Note: The pH, Temp, and TDS are entered automatically as the numbers are available from the measurement and automation system. Each time this display is entered, if available, the current temperature is obtained from the Automation controller (IntelliTouch, EasyTouch, etc), TDS is obtained from the IntelliChlor SCG. But these values can be changed on this screen for calculation purposes.

**pH:** Enter the current pH value.

**Temperature:** Enter the current temperature setting.

**CH:** Enter the current calcium hardness level.

**TDS:** Enter the current Total Dissolved Solids level.

**TA:** Enter the current total alkalinity value.

**CYA:** Enter the current cyanuric acid value.

**SI:** Displays the last calculated SI value (Corrosive/Scaling/Ideal). **Note: If there is no flow or Flow Delay is enabled, no SI value displayed.**

### Sat Index (Continued)

pH: 6.0	Temp: 77F	pH: 6.0	Temp: 77F
CH: 250	TDS1000	CH: 250	TDS1000
TA: 90	CYA:18	TA: 90	CYA:18
SI = N/A No Flow		SI = N/A FlowDelay	

### Recommended Pool Chemistry

<b>pH range:</b>	<b>7.2 to 7.6</b>
<b>ORP range:</b>	<b>650 to 750</b>
<b>Alkanlinity:</b>	<b>80 to 120 ppm</b>
<b>Calcium Hardness:</b>	<b>200 - 500 ppm</b>
<b>Cyanuric Acid/Stablizer:</b>	<b>30-50 ppm</b>

**pH:** Chlorine produced by the IntelliChlor SCG is close to Neutral pH. However, other factors usually cause the pH of the pool water to rise. Therefore, the pH in a pool chlorinated by IntelliChlor tends to stabilize at approximately 7.8. This is within APSP standards. If the pool pH rises above 7.8, have a pool professional test to see if other factors such as high Calcium Hardness or Total Alkalinity are the cause and then balance accordingly.

**Temperature:** The pool water temperature can affect the saturation index value.

**pH Level Test:** Test the pH level of your pool water with a reliable test method. If necessary, adjust according to your pool professional's recommendations. APSP's recommended ideal range for pH is 7.2 to 7.6. Note: Never use dry acid (sodium bisulfate) to adjust pH in arid geographic areas with excessive evaporation and minimal dilution of pool water with fresh water. A buildup of byproducts can damage the IntelliChlor SCG

#### Calcium Hardness

Recommended range for calcium hardness is 200-500 ppm. Calcium Hardness levels should be tested weekly. Calcium hardness is the calcium carbonate scale deposited on pool surfaces. The test for Calcium Hardness is a measure of how "hard" or "soft" the water is testing. "Hard" water can have high levels of calcium and magnesium. If these levels are too high the water becomes saturated and will leave calcium carbonate scale deposits (a "white-ish," crystallized rough spot) on any surface inside the pool. If the levels are too low, the water becomes "soft" and will corrode surfaces inside the pool. Use TSP or Hydroquest 100 to lower Calcium Hardness levels that are too high or add water to the pool which has a lower calcium hardness content. Levels which are too low require the addition of calcium chloride.

**Total Dissolved Solids (TDS):** Adding salt to pool water will raise the TDS level. While this does not adversely affect the pool water chemistry or clarity, the pool water professional testing for TDS must be made aware salt has been added to the IntelliChlor system. The individual performing the TDS test may then subtract the salinity level to arrive at a TDS level that would be compatible to a TDS reading for a non-salt water pool.

**Note: If a salt chlorine generator is being used for your pool, the salt level is the TDS level of the pool.**

## Sat Index (Continued)

### Total Alkalinity

APSP's recommended ideal range for total alkalinity is 80 to 120 ppm for "gunite" and concrete pools and 125-170 ppm for painted, vinyl, and fiberglass pools. Test levels weekly and adjust according to your pool professional's recommendations. Total Alkalinity can be described as a buffer that keeps pH in order. pH depends on the ability of the total alkalinity in the water to withstand the changes in pH. If the total alkalinity is too high, adding acid (similar to pH) lowers the level. Adding a base (e.g. sodium bicarbonate) when total alkalinity is low, raises the level. The level of total alkalinity in the water is a measurement of all carbonates, bicarbonates, hydroxides, and other alkaline substances found in the pool water.

**Cyanuric Acid:** Cyanuric acid is needed in outdoor pools to help to stabilize and maintain proper levels of chlorine. 90% of unstabilized chlorine is destroyed by the UV radiation from the sun. Cyanuric acid stabilizes chlorine in water from UV degradation. When using the IntelliChlor SCG, the cyanuric acid level should be maintained between 30-50 ppm.

### Optimum Pool Water Chemistry Conditions for Salt Water Pools (using the IntelliChlor SCG)

In accordance with the Association of Pool and Spa Professionals (APSP) standards, it is recommended that the pool water chemistry conditions (see page 21) be maintained on an on going basis to help protect pool users, pool related equipment and surfaces in and around the pool. These values are important to maintaining the pool equipment in proper operating condition and preventing corrosion, liming or other problems. The IntelliChlor Electronic Chlorine Generator is warranted to operate properly only if these conditions are met. For more information, refer to your local agency having jurisdiction, NSPI (National Spa and Pool Institute), the CDC (Centers for Disease Control), or the WHO (World Health Organization). Recommended pool water chemistry is given below:

**Free Chlorine:** 2.0 - 4.0 ppm. Above 4.0 ppm may cause corrosion of metal components

**Combined Chlorine (Chloramines):** None (super chlorinate to remove all chloramines)

**pH:** 7.2 - 7.8 (USE MURIATIC ACID to lower pH and Soda Ash to raise pH.)

**Cyanuric Acid:** 30 - 50 ppm

**Total Alkalinity:** 80 - 120 ppm

**Calcium Hardness:** 200 - 400 ppm

**TDS (includes salt):** 3000 minimum to 5700 to 6000 maximum ppm

**Salt:** 3000 - 4500 ppm (ideal 3400 ppm)

**Metals (Copper, Iron, Manganese):** None

**Nitrates:** None - **Phosphates:** Less than 125 ppb

### Using the Langelier Saturation Index (LSI) to Diagnose Water Balance

Use the **Langelier Saturation Index (LSI)** calculator to diagnose the water balance in your pool. Water with a LSI of 1.0 is one unit above a balanced condition. Reducing the factors by 1 unit will bring the water into equilibrium. To use the LSI calculator, refer to: <http://www.pentairpool.com/pool-owner/resources/calculators/langelier/>

## Sat Index (Continued)

### Calculating the Saturation Index

The saturation index is a formula that relates pH, calcium and alkalinity in the pool water. A well balanced pool water will have a formula result range between -0.3 and 0.3. Outside this range, the pool water is out of balance, potentially damaging pool equipment or scaling the salt chlorine generator. The equation to calculate Si is:


$$SI = pH + CHF + AF + TF - TDSF$$

Saturation Index      pH tested      Calcium Hardness Factor      Alkalinity Factor      Temperature Factor      TDS Factor (21.1 non-salt, 12.2 salt pools)

Cyanuric acid in the form of cyanurate ions contribute to alkalinity. Thus, a correction must be made to total alkalinity. We subtract 1/3 of the cyanuric acid level from the reading obtained in the total alkalinity test.

#### Total Alkalinity - 1/3 Cyanuric Acid = Corrected Alkalinity

This correction can be considerable in established pools with high cyanuric acid levels; for example, at 240 ppm cyanuric acid, the correction amounts to 80 ppm ( $240 \div 3 = 80$ ).



### Saturation Index Tables (as recommended by NSPF)

Temperature		TF	Calcium Hardness		Total Carbonate Alkalinity	
°F	°C		ppm (mg/L)	CHF	ppm (mg/L)	AF
32	0.0	0.0	25	1.0	25	1.4
37	2.8	0.1	50	1.3	50	1.7
46	7.8	0.2	75	1.5	75	1.9
53	11.7	0.3	100	1.6	100	2.0
60	15.6	0.4	125	1.7	125	2.1
66	18.9	0.5	150	1.8	150	2.2
76	24.4	0.6	200	1.9	200	2.3
84	28.9	0.7	250	2.0	250	2.4
94	34.4	0.8	300	2.1	300	2.5
105	40.6	0.9	400	2.2	400	2.6
			800	2.5	800	2.9

## INSTALLATION (INTELLICHEM AND FLOW CELL)

### Before Installing the IntelliChem

Before installing the IntelliChem controller, read the following instructions.

1. **IMPORTANT!** If the equipment pad is below the water level of the pool, please install a CHECK VALVE **after** the heater or use a Hartford Loop.
2. Identify new and existing equipment to be connected.
3. Decide if the sensors will be in a separate by-pass line, or if the Flow cell will be used. **Caution: If the Flow Cell is being installed, the input water maximum pressure is 25 PSI.**
4. Determine the supply voltage, 110 VAC or 220 VAC, and wire the transformer wires as needed (see page 30).
5. Determine if the control to the equipment uses the same voltage as the supply voltage. All controlled equipment must be compatible.
6. Determine the water-tap points for the flow cell bypass inlet and outlet.
7. Mount the Flow Cell away from direct sunlight and on a flat vertical surface.
8. Connect the supply voltage with main house circuit breaker off. (Must be a separate dedicated circuit GFCI).
9. If using a Flow Cell install the bypass now.
10. Connect the pH and ORP sensors.
11. Test the plumbing for leaks.
12. Switch on the IntelliChem system for the first time as described below.



#### **Risk of Electrical Shock or Electrocution!**

IntelliChem must be installed by a licensed or certified electrician or a qualified pool professional in accordance with the National Electrical Code and all applicable local codes and ordinances. Improper installation will create an electrical hazard which could result in death or serious injury to pool users, installers or others due to electrical shock, and may also cause damage to property.



Always disconnect the power to the IntelliChem enclosure at the circuit breaker before servicing the light. Failure to do so could result in death or serious injury to serviceman, pool users or others due to electrical shock.

## Mounting IntelliChem Enclosure

Mount the IntelliChem enclosure as follows:

1. Select a location for mounting the IntelliChem enclosure with the following required recommendations:
2. Install the IntelliChem enclosure at least 10 feet from the pool or spa wall.
3. Supply power must be routed to the IntelliChem in accordance with the applicable national and local (NEC) codes (see page ii).
4. The installation surface must be solid and vertical. Do not mount the IntelliChem enclosure in a horizontal position.
5. Maintain adequate clearance for opening the enclosure.
6. The environment should be free of chemical fumes and excessive heat. The maximum temperature is should not exceed 110 °F (50 C).
7. Mount as far as possible from sources of electrical interference.
8. Mount the enclosure on a flat surface.
9. Hold the IntelliChem enclosure against the mounting surface with a closed lid and mark the location of the mounting brackets located on the sides of the enclosure next to the wall. Prepare holes as necessary and secure enclosure using the provided mounting screws.
10. Install a conduit into the controller enclosure.



**WARNING** Locate the chemical feed pumps and the chemical storage tanks in a safe and secure area. Never turn the chemical feed pumps on when both flow cell valves are closed. Increased pressure may cause the feed lines to blow off and spray full strength chemicals on anyone or anything near the equipment. Securely fasten all electrical, water, and chemical lines.



## Wiring the IntelliChem Transformer for 120 VAC or 240 VAC

**⚠ DANGER**



**DANGER!**

### RISK OF ELECTRICAL SHOCK OR ELECTROCUTION

Always disconnect AC power to IntelliChem at the circuit breaker before servicing. Failure to do so could result in death or serious injury to installer, serviceman, pool users, or others due to electrical shock.

### High Voltage Wiring


The high voltage wiring compartment is located inside the IntelliChem enclosure. The IntelliChem system can be connected either to 120 VAC or 240 VAC. The IntelliChem system should be wired to receive power from the filter pump. The maximum current rating is 200/100 mA at 120/240 VAC (60 or 50 Hz). Wire AC power into the IntelliChem enclosure from the main circuit breaker at the house. There is no ground/bonding terminal required at this non-metallic enclosure. Follow manufactures instructions when installing and testing of ground fault circuit breakers (GFCB) and interrupters (GFCI).

Connect input AC wires to the IntelliChem transformer wires as follows:

- **120 VAC:** Connect one 120 VAC source wire to the Brown/Black wires connected together and one wire to the Blue/White wires connected together.
- **240 VAC:** Connect one 240 VAC source wire to White wire and one wire to Brown wire. The Black/Blue wires are connected together.

#### Transformer Wiring

Input: 240/120 VAC  
50/60Hz  
(Series/Parallel) 56 VA




## Connecting External Devices to IntelliChem

**External Devices** such as pumps, CO2 devices and alarms can be connected to either of the dry contact relays (EX\_RELAY 1 and EX\_RELAY 2). Relay contact ratings: 5 AMPS, 250VAC/30VDC located on the IntelliChem circuit board. See wiring diagram below and “Plumbing Installation” on page 37.

**⚠ DANGER** BE SURE TO DISCONNECT ALL SUPPLY CONNECTIONS BEFORE SERVICING INTELLILCHEM. AC Power may be supplied to the relay terminals Ex\_Relay1 and Ex\_Relay2 from other sources.

**⚠ WARNING** Wiring external devices must be performed by a licensed or electrician or a qualified pool professional in accordance with the National Electrical Code (NEC), NFPA 70 or the Canadian Electrical Code (CEC), CSA C22.1. All applicable local installation codes and ordinances must also be adhered to. Improper installation will create an electrical hazard which could result in death or serious injury to pool users, installers or others due to electrical shock, and may also cause damage to property.




External Device Wiring Diagram

### Installing the Flow Cell and pH/ORP Sensors (Kit Contents)

**WARNING** pH and ORP sensors are shipped with a protective cap covering the electrode tip of the probes to protect the sensing element. DO NOT MIX THESE CAPS - Solutions will destroy the other type of probe. Sensors should be kept in the protective cap until ready for installation, if the sponge in the boot becomes dry, wet it with pool water. Before using the sensor remove the cap.

### IntelliChem Kit Contents




Item #	Qty.	Part #	Description
1	3	R18706	COMPRESSION NUT
2	3	R18715	TUBE, FITTING
3	3	R172033	GASKET,.75 OD
4	3	R172034	CLAMP, SADDLE
5	1	R172036	LUBRICANT, SILICONE,3/4OZ
6	2	606000100	FTG 3/8" COMPRESSION X 1/4" NPT
7	1	521436	FTG 1/4" COMPRESSION X 3/8" COMPRESSION
8	1	620000190	FTG 1/4" COMPRESSION X 1/4" NPT
9	1	640000100	1/2" X 260' TEFLON® TAPE
10	3	622000080	1/4" NPT M/F BALL VALVE
11	2	620000040	FTG 1/4" NPT NYLON PLUG
12	6	624000270	SCR WOOD 12 X 3/4 PPH SS
13	6	625000020	PLASTIC SREW ANCHOR
14	1	R28033	POLY BAG,6" X 10" , 3 MIL

### Mounting the Flow Cell

Remove Flow Cell from shipping carton and select a suitable location for the flow cell within 10 feet of the IntelliChem controller.

Note: The 3/8" flexible tubing that is required to connect the flow cell to the rest of the system is included with IntelliChem kit.



### Installing the pH and ORP Sensors (Read This First)


Install the pH and ORP sensors as follows: For IntelliChem Plumbing Installation Diagram, see page 37.

1. Sensors wires will connect to within 10 feet.
2. Water leaks will cause damage! Mount where water does not leak and damage other components.
3. Mount flow cell vertically with provided screws.
4. Securely fasten all electrical, water and chemical lines.
5. Locate chemical feed pumps and chemical storage tanks in a safe and secure area.
6. Maximum operating pressure = 25 psi.
7. Extreme pressure variances may affect readings and can cause damage to the sensors.
8. Avoid installing the outlet before the main pump as the vacuum may damage the chemical sensors.
9. Only inject chemicals on the outlet side of the IntelliChem Flow Cell
10. Do not over tighten fittings on flow cell top.

### Installing the pH and ORP Sensors

To install the Flow Cell pH and ORP sensors:

1. Keep pH and ORP sensors wet at all times, install the sensors into the flow cell. **Hand-tighten only** and save caps for future use (DO NOT MIX THESE CAPS), fill flow cell with water. The sensors have O-Rings and don't require Teflon<sup>®</sup> tape.
  - Do not rub hard on the glass element in the sensor or use sand paper or other polishing material to clean.
  - Handle electrode carefully.
  - Sensors contain external and internal glass elements.
  - Do not drop or otherwise subject the sensor to vibration, physical impact, or freezing conditions.
  - Leave excess wire outside the controller enclosure. If the cable is longer than needed, it should be coiled neatly and attached under the controller enclosure.
  - DO NOT CUT THE SENSOR WIRES. Do not stuff excess wire inside the controller as this may cause excess strain on sensor and relay connections.



## Plumbing the Flow Cell


**⚠ WARNING** Be sure to have a licensed plumber perform all plumbing; this is important, as they will be familiar with all of the codes in the local area.

To connect the Flow Cell to the system plumbing: See page 37 for plumbing diagram.

1. At the equipment pad, switched off the filter pump and release the pressure from the system by opening the valve on top of the filter.

**⚠ WARNING** WARNING CHEMICAL BURN HAZARD: Make sure all pumps are switched off at the main circuit breakers at the house before drilling into any pipes. Securely fasten all electrical, water and chemical lines. Locate chemical feed pumps and chemical storage tanks in a safe and secure area.

2. Close all valves to prevent flooding.
3. Attach the IN and OUT tubes to the Flow Cell Inlet and Outlet (see Tubing Installation Diagram shown below).
4. Run the end of the IN tube to the chosen pressure line. Choose a location that provides enough space to drill and to tighten the clamp (must be after the filter, but before the heater). Be sure the tube is not pinched or kinked. Mark a spot on the pipe.
5. Install the supply and return lines for each flow cell. Drill and tap 3/8" holes for the 3/8" flexible tubing on the mark and immediately place the fitting into the pipe. Align the fitting with the hole and tighten.
6. Locate where the water will be supplied from and returned for each flow cell. The most common location for the water inlet to the flow cell is AFTER the main filter and BEFORE the heater.
7. Run the end of the OUT tube (with the pipe clamp) to the chosen return line. Choose a location that provides enough space to drill and to tighten the clamp (**must be after the heater**). Be sure the tube is not pinched or kinked. Mark a spot on the return line pipe.
8. Drill and tap 1/4" holes for the 1/2" flexible tubing on the mark and immediately place the pipe clamp over the pipe. Align the fitting with the hole and tighten the pipe clamp.
9. Open any closed system valves. Close the filter valve and turn on the circulation system. Check that the system is working properly.



IntelliChem Tubing Installation Diagram

## Plumbing the Flow Cell (Continued)

**⚠ WARNING** Do not inject acid directly in to the flow cell. Injecting acid in this way may damage the existing pool equipment.

10. Locate the chemical injection points.
11. Prepare and install the chemical injector fittings.
12. Install the chemical storage containers.
13. Turn ON the main circulation pump.
14. Check for leaks and verify the flow sensor indicates flow.


### Flow Cell Inlet and Exit Lines

1. It is essential that the supply line be at a higher pressure than the discharge line so the water will flow through the cell at a steady rate in the right direction.
2. Inlet should be installed after filter and before heater.
3. Exit should be installed after heater and as far away from any equipment as possible.
4. Choose a location on a fitting where the pipe enters so you are drilling through both the pipe and fitting to get maximum depth of thread.
5. Install ¼" NPT flex fittings then route inlet and exit lines.

**⚠ WARNING** Make sure all pumps are OFF before drilling into pipes. Never switch ON chemical feed pumps without the pool filter pump also running.

**⚠ CAUTION** The flow switch is a dry contact only (no current). Use with any other brand of flow switch voids WARRANTY and UL listing.

# IntelliChem Installation Plumbing Diagram



**⚠ WARNING** HAND TIGHTEN FITTINGS ONLY: USING A WRENCH TO TIGHTEN WILL CRACK FITTINGS

Figure 2: IntelliChem Plumbing Installation Diagram

### Connecting the pH and ORP Sensors Wires to IntelliChem Circuit Board

**WARNING** The Flow Switch is a Dry Contact Only (No Current). This Flow Switch should only be used with IntelliChem. Use of this Flow Switch with any other brand of controller will void the warranty and UL listing.

1. Route the Flow Cell switch wires into the IntelliChem enclosure through the strain relief and connect the wires to **J6 Sensor terminal connector** on the IntelliChem circuit board. **Connect the BLACK wire to the GND screw terminal and the RED wire to the FLOW screw terminal.**
2. Route the pH and ORP sensor wires into the IntelliChem enclosure through the strain relief and connect to J6 Sensor terminal connector on the IntelliChem circuit board. The sensor wires are labeled. PLUS AND MINUS POLARITY MUST BE OBSERVED.

**pH sensor wire:** Connect the GREEN to the pH - screw terminal and the CLEAR wire to the pH + screw terminal.

**ORP sensor wire:** Connect the GREEN to the OPR - screw terminal and the CLEAR wire to the ORP + screw terminal.




Figure 2: IntelliChem J6/J7 Circuit Board Wiring Connections

3. Turn the main pump on and open the valves to test for leaks and the free movement of magnet. Magnet must be all the way up in order to close the flow switch. 1/4 GPM will push the magnet all the way up.

**WARNING** Make sure that all pumps are off before drilling into any pipe.

**WARNING** Never turn chemical feed pumps on when either flow cell valve is closed.


**CONNECTING INTELLICHEM TO AN AUTOMATION CONTROL SYSTEM****Wiring IntelliChem AC Power to Filter Pump Relay**

**IntelliChem AC Power Wiring Instructions:** When using IntelliChem as a stand alone device (with a time clock) or with an IntelliChlor salt chlorine generator, IntelliChem **MUST BE CONNECTED TO THE PUMP SIDE OF THE MAIN FILTER PUMP RELAY** located in the load/power center (see page 40 for IntelliChem AC power wiring diagram). This ensure that IntelliChem will only dispense chemicals when the filter pump is ON.

For IntelliTouch®, EasyTouch® or SunTouch® automation control system using an IntelliFlo® pump (or 2-speed pump) and an IntelliChlor® (SCG), the IntelliChlor AC power center wires must also be connected to the **PUMP SIDE OF THE MAIN FILTER PUMP RELAY** located in the load/power center (see page 40 for diagram). This ensures that IntelliChem and IntelliChlor only produce chlorine when the main filter pump is on.

The following wiring diagram (see next page) shows the IntelliChem AC power wiring and COM port connections to the EasyTouch, IntelliTouch and SunTouch automation control system.

**IntelliChem AC Power and COM port (RS-485) Wiring Diagram**



**Note:** For more information about operating automation pool controllers, refer to the following manuals:

- IntelliTouch User's Guide (P/N 520102)
- EasyTouch User's Guide" (P/N 520584)
- SunTouch User's Guide" (P/N 520785)

## CONNECTING INTELLICHEM TO AN AUTOMATION CONTROL SYSTEM

### Wiring IntelliChem AC Power to Filter Pump Relay

**IntelliChem AC Power Wiring Instructions:** When using IntelliChem as a stand alone device (with a time clock) or with an IntelliChlor salt chlorine generator, IntelliChem **MUST BE CONNECTED TO THE PUMP SIDE OF THE MAIN FILTER PUMP RELAY** located in the load/power center (see page 40 for IntelliChem AC power wiring diagram). This ensure that IntelliChem will only dispense chemicals when the filter pump is ON. Note:  
 For IntelliTouch®, EasyTouch® or SunTouch® automation control system using an IntelliFlo pump (or 2-speed pump) and an IntelliChlor (SCG), the IntelliChlor AC power center wires must also be connected to the **PUMP SIDE OF THE MAIN FILTER PUMP RELAY** located in the load/power center (see page 40 for diagram). This ensures that IntelliChem and IntelliChlor only produce chlorine when the main filter pump is on.

To connect IntelliChem AC power wires to EasyTouch, IntelliTouch and SunTouch filter pump relay (see diagram on previous page).


**⚠ DANGER**

**D A N G E R !**


#### **RISK OF ELECTRICAL SHOCK OR ELECTROCUTION**

Always disconnect AC power to EasyTouch, IntelliTouch and SunTouch load/power center at the circuit breaker before servicing, or removing the HIGH VOLTAGE FRONT PANEL. Failure to do so could result in death or serious injury to installer, service person, pool users, or others due to electrical shock.

1. **IntelliChem AC power:** Run the IntelliChem AC power wires to the EasyTouch, IntelliTouch or SunTouch enclosure.
2. **EasyTouch/IntelliTouch Load Center:** Unlatch the enclosure door spring latch, and open the door.
3. **Discharge Electrostatic energy before removing the cover by first touching the metal part of the enclosure.**
4. Loosen the two (2) retaining screws from the HIGH VOLTAGE FRONT PANEL. Remove the panel from the enclosure.
5. Connect the IntelliChem AC power cord wires to the LOAD/PUMP SIDE of the main filter pump relay (see wiring diagram on page 40).
6. When the connection is completed: **EasyTouch/IntelliTouch:** Close the control panel and secure it with the two (2) retaining screws. **SunTouch:** Close the front control panel and secure with the retaining screw.
7. Close the load center front door. Fasten the spring latch.




**CONNECT INTELLICHEM AC POWER TO FILTER PUMP RELAY**



Load Center (with SCG option)

**CONNECT INTELLICHEM AC POWER TO FILTER PUMP RELAY**



Power Center (with SCG option)

IntelliChlor (SCG) Transformer

### Connecting IntelliChem RS-485 Communication Cable to the Automation Control System Circuit Board

To connect IntelliChem COM Port Cable to EasyTouch, IntelliTouch and SunTouch COM port (see diagram on page 36):

1. **IntelliChem RS-485 cable:** Strip back the cable conductors  $\frac{1}{4}$  in. Insert the wires into the connector screw terminals. Make sure to match the color coding of the wires; YELLOW = +DATA, GREEN = -DATA and BLACK = GND. Secure the wires with the screws.
2. Run an RS-485 cable from the IntelliChem enclosure to the EasyTouch, IntelliTouch or SunTouch enclosure.
3. Unlatch the load center/power center enclosure door spring latch, and open the door.
4. **WARNING! Switch AC power OFF to load/power center before installation (see note on page 41) EasyTouch/IntelliTouch Load Center:** Loosen the two (2) retaining screws from the control panel.
  - (a) Lower down the control panel on its hinges to access the motherboard located behind the control panel.
  - (b) Route the IntelliChem RS-484 cable up through the low voltage raceway in the load center to the motherboard.

**SunTouch Power Center:** Route the conductor cable up through the lower grommet opening into the enclosure.
5. Strip back the IntelliChem cable conductors  $\frac{1}{4}$  in. Insert the wires into the COM port connector screw terminals on the circuit board: (**EasyTouch J20, IntelliTouch J7/8, SunTouch J11**). Make sure to match the color coding of the wires; YELLOW = +DATA, GREEN = -DATA and BLACK = GND. Secure the wires with the screws.
6. When the connection is completed: **EasyTouch/IntelliTouch:** Close the control panel and secure it with the two (2) retaining screws. **SunTouch:** Close the front control panel and secure with the retaining screw.
7. Close the load center front door. Fasten the spring latch.

### Setting Up IntelliChem with IntelliTouch, EasyTouch & SunTouch

#### IntelliTouch Automation Control System

The following describes how to setup IntelliChem from the IntelliTouch control panel. From the IntelliTouch control panel you can adjust the pH and ORP set point values, view the IntelliChem status and monitor your pool water condition using the Saturation Index. To access the IntelliChem screens, from the IntelliTouch Indoor Control Panel or the wireless MobileTouch® control panel:



**PH/ORP Values:** The pH and ORP values are displayed next to the set point settings.

**pH Set:** Displays the current pH set point value. The adjustable range is from 7.2 to 7.6 in increments of 0.1. The default pH set point value is 7.5. To adjust the pH set point, press the button next to pH Set.

**ORP Set:** Displays the current ORP set point value. The adjustable range is from 650 to 800 in increments of 10. The default ORP set point value is 700. The ORP set point is the value that IntelliChem will try to achieve based on the actual chlorine level (ppm). To adjust the ORP set point, press the button next to ORP Set.

**STATUS:** Displays the current communication link between IntelliTouch and IntelliChem via the RS-485 cable. **IChem Comm Error:** Check the RS-485 communication cable is connected to the COM port on the IntelliTouch Personality circuit board.

**USING SCG:** “USING SCG” displays if the IntelliChlor salt chlorine generator is enabled. The SCG is enabled and disabled from the MENU > SETUP > EQUIPMENT > CHLORINATOR screen.

**Note:** IntelliChem must also be set up to use the IntelliChlor SCG either with the **AUTO SETUP Setup Wizard (page 6)** or the **Configuration/Hardware/ORP Control/Doser Type (page 23)**.

**DISABLE/ENABLE INTELLICHEM:** To disable IntelliChem, press the button under DISABLE ICHEM. To enable IntelliChem, press the button next to INTELLICHEM. On the next screen press button next to NO and select **YES**. Press **SAVE** to save the setting and return to the Equipment screen.

**Saturation Index/Menu:** To access the Saturation Index screen, press the button next to SATURATION INDEX/MENU. The current Saturation Index value, water condition, water temperature and Total Dissolved Solids (TDS) are displayed. Press the button next the following selections to adjust the levels/values:




**Calcium Hardness:** Recommended range is 200-400 ppm. Levels should be tested weekly.

**Cyanuric Acid:** Stabilizes chlorine in water from UV degradation. When using the IntelliChlor SCG, cyanuric acid level should be maintained between 30-50 ppm. **Total Alkalinity:** APSP’s recommended ideal range for is 80 to 120 ppm

for “gunite” and concrete pools and 125-170 ppm for painted, vinyl, and fiberglass pools. Test levels weekly and adjust according to your pool professional’s recommendations.

**Saturation Index:** The saturation Index displays IDEAL (Optimum levels), CORROSIVE or SCALING. The following are recommended pool chemistry Saturation Index levels: **pH range: 7.2 to 7.6 ORP range: 650 to 800. Alkanlinity: 80 to 120 ppm. Calcium Hardness: 200 - 500 ppm. Cyanuric Acid/Stabilizer: 30-50 ppm.**

**Note:** See page xx for information the online **Langelier Saturation Index (LSI) Calculator** to diagnose the water balance in your pool.



## Setting Up IntelliChem with EasyTouch Control System

### EasyTouch Automation Control System

The following describes how to setup IntelliChem from the EasyTouch control panel. From the EasyTouch control panel you can adjust the pH and ORP set point values, view the IntelliChem status and monitor your pool water condition using the Saturation Index. To access the IntelliChem screens, from the EasyTouch Indoor Control Panel or the EasyTouch wireless control panel: **Press MENU > SETTINGS > INTELLICHEM**

Clock ▲  
IntelliFlo  
IntelliChlor  
▶ IntelliChem ▼

IntelliChem  
▶ PH/ORP Values  
Status  
Sat Index

pH VAL 7.0  
pH Set: 7.5  
ORP VAL: 650  
ORP SET: 750

IntelliChem  
PH/ORP Values  
▶ Status  
Sat Index

pH Lv1: ▯  
ORP Lv1: SCG  
ICHEM: ON  
ORP Dosage Limit

IntelliChem  
PH/ORP Values  
Status  
▶ Sat Index

CH: 245 TDS: 0  
TA: 75 CYA: 30  
SI: NA TMP: 0  
IDEAL

**PH/ORP Values:** Press the **Right button** to access the pH and ORP set point values screen. Use the **Up/Down button** to adjust the pH set point value. Press the **Right button** again to set the ORP set point value. Press **MENU** to save and return to the previous screen.

**pH Set Point:** Displays the current pH set point value. The adjustable range is from 7.2 to 7.6 in increments of 0.1. The default pH set point value is 7.5.

**ORP Set Point:** Displays the current ORP set point value. Use the **Up/Down button** to adjust the ORP set point value. The adjustable range is from 650 to 800 in increments of 10. The default ORP set point value is 700. The ORP set point is the value that IntelliChem will try to achieve.

**STATUS:** Displays the current communication link between EasyTouch and IntelliChem via the RS-485 cable. **IChem Comm Error:** Check the RS-485 communication cable is connected to the COM port on the EasyTouch circuit board.

**Level Gauge indicator:** Press the **Up/Down button** to “fill” the gauge icon so that it visually represents the same amount of acid available in the container. Press Up/Down button six (6) times to fill the gauge (three times to half fill the gauge). Six horizontal bars represent chlorine (or bromine) supply is full. One bar indicates the supply is nearly empty.

**Note: IntelliChem must also be set up to use the IntelliChlor SCG either with the AUTO SETUP Wizard (page 6) or the Configuration/Hardware/ORP Control/Doser Type (page 23).**

**Sat Index:** To access the Sat Index settings, press the **Up/Down button** then press the **Right button**. Use the **Up/Down button** to adjust the levels/values for: **CH (calcium hardness)**, **TDS (Total Dissolved Solids)**, **TA (total alkalinity)**, **CYA (cyanuric acid)** and **TMP (current temperature)**. **Note: See table below for ideal Saturation Index levels.**  
**SI:** The saturation Index is displayed. IDEAL: Optimum levels. CORROSIVE or SCALING: Press the **Menu** button three times to return to the main screen.

**Note:** See page 26 for information the online **Langelier Saturation Index (LSI) Calculator** to diagnose the water balance in your pool.

## Setting up IntelliChem with SunTouch Control System

### SunTouch Automation Control System

The following describes how to view the current IntelliChem pH and ORP levels from the SunTouch control panel. To access the IntelliChem screens **Press MENU > DIAGNOSTICS > INTELLICHEM**

**IntelliChem**  
**pH: 7.65 ORP:832**

Displays the current pH and ORP levels. IntelliChem is connected to the SunTouch control system via the RS-485 cable. The RS-485 communication cable is connected to the COM port on the SunTouch circuit board.

## TROUBLESHOOTING

### General Troubleshooting Guide

1. Run Meter Self-Test (see Configuration menu)
2. Run Probe-Open Test (see Configuration menu)
3. Clear pH and ORP Tweaks (see Configuration menu)
4. Clean Sensors (see Maintenance section)
5. Check chemicals and feed system
6. Take sample of pool water for analysis of CYA, alkalinity, check saturation index, Balance water
7. Replace Sensors
8. Repeat above steps

### Diagnostics Self Test

The overall functionality of the IntelliChem can be verified by running the self test. Access this feature in the Configuration/Diagnostic menu. The test verify the LCD display, front panel LED indicators, push buttons, flow switch input, doser motors, relays, the RS-485 communication, and the meter.

**Warning! This test will turn on the doser, so be sure that the tubing is installed in a safe manner so that the chemicals will be safely contained.**

### Help guide (See page 47)

This guide presents a logical approach to solving problems you will likely encounter with maintaining your pool water.

### General Guidelines

#### pH or ORP not able to reach setpoint

This may be a common issue that can easily be resolved by increasing the amount of chemical dispensed each day. If the pH Sensitivity is set to "Low" (the default), IntelliChem will only administer the full dose at 0.5 from setpoint. If it seems to be stuck 0.3 from setpoint, you're only getting 3/5 of the programmed dose. Change the Sensitivity to "High" and you'll get the full dose at 0.2 pH or greater from setpoint. Or, turn pH Sensitivity OFF - only turn it on if you're overshooting the setpoint.

Increasing the dose would essentially do the same thing. Increase the dosage as well as the dose-limit and reduce the mix time so you still get all 8 doses in the filter run time.

## Help Guide

Sequence	Access	Action
Meter Test	Menu/Configuration/Diagnostics Run Meter Test	Use this test to verify that the pH and ORP sensing circuitry and meters are operating properly. The test first shows diagnostic uncalibrated values for test circuit H, then test circuit L. It then runs the Auto Calibration and shows two values for each. If the bottom line shows *** PASS *** the meter and sensing circuitry is good. If the test fails, these values can be used at the factory to determine which part of the circuit is faulty.
Probe Test	Menu/Configuration/Diagnostics Run Meter Test	This is a 30 second test that evaluates the inputs to the pH and ORP meters. The results are used to determine if the probes are functioning. It will accurately detect if a probe is disconnected or has broken or shorted wires. It will not be able to assess if the probes are dirty, old, cracked, etc; so it is not necessarily an indication that the probes may not have other problems. If problems persist, replace the probe with a new or known-good probe.
Clear Tweaks	Menu/pH Menu/pH Tweak Menu/ORP Menu/ORP Tweak	Set tweak: to 0. Often problems with a pool are the result of "miscalibrated" probes. This screen shows the user's offset and the final reading. Under ideal circumstances the meter should read the water correctly without any tweak adjustment.
Clean Probes	At flow cell	See cleaning instructions. See page 52 and 53.
Check Dosers	pH Settings button/Override ORP Settings button/Override	Select [Dose] to turn on the appropriated doser. The doser selection is specified in the Configuration/ Hardware/pH Control and /ORP Control menus. Verify the pump is rotating properly and tubing is installed correctly. Check proper direction of flow. Pumps are labeled with IN and OUT and turn clockwise. One outlet is toward the front of the IntelliChem, the other is toward the wall. Verify pickup tube is all the way to the bottom of the container. Once verified, let the pumps run for a while to prime the tubing using the Dose Override feature. <b>WARNING!</b> Use extreme caution when handling pool chemicals. Verify the tubing is not clogged, kinked or punctured.
Chemicals	Supplies for the doser pump Set levels in pH/ORP Settings button or in the pH/ORP Supplies Menu.	Verify chemicals are fresh and of the proper concentration. Muriatic acid and Chlorine degrades within a matter of months or less depending on sunlight and temperature. Be sure the supply containers contain sufficient amounts of chemical. Set the Supplies level to correspond to the level in the tank. Once the indicator gets to the "0" level, the alarm will be set
Sat Index	Main menu, Sat Index	The Langelier Saturation Index is an indication of the overall water condition. Its calculation is based on water temperature, pH, salt, calcium hardness, and total alkalinity (to which cyanuric acid has a contributing factor). The results of this calculation are used to determine if the water is corrosive or scaling. Balanced water allows the pool chemicals to function properly and affects the ability of the sanitizer to do its job. If you're having problems with maintaining water clarity or sanitizer, check this or have a water sample professionally analyzed.
Balance Water		Balance water is the result of proper chemical treatment and care of the filtration
Replace Probes		If the probes have been cleaned and all other aspects of the pool operating properly. Try a new set of probes.
Repeat		After performing all these steps it may prove helpful to repeat all these steps

## Alarm Messages and Troubleshooting Tips

The IntelliChem is continually monitoring its own condition and that of the water chemistry. The following is a list of alarms and most likely causes. This should give you a good starting place for troubleshooting and resolving the alarm.

### Diagnostics Self Test

The overall functionality of the IntelliChem can be verified by running the self test. Access this feature in the Configuration/Diagnostic menu. It tests the LCD display, front panel LED indicators, push buttons, flow switch input, doser motors, relays, the RS-485 communication, and the meter.

Warning: This test will turn on the doser, so be sure that the tubing is installed in a safe manner so that the chemicals will be safely contained.

## Troubleshooting the alarm messages

IntelliChem Message**	EasyTouch/IntelliTouch, Screen Logic	Troubleshooting Tips
SI Scaling / SI Corrosive	SI Scaling SI Corrosive	Water conditions indicate water has exceeded the threshold level. Refer to Langelier Saturation Index water balance information and the user settings in the Configuration/Preferences 2/2 page
UOC Comm Err	Comlink Lost Communication Lost	Connection between IntelliChem and the automation controller. Check RS-485 4-wire connection, terminals, and cables.
Auto Calibration ...Failed	Auto Cal Failed	Check that the printed circuit board is clean and dry. Dirt, condensation or water leaking into the enclosure will cause faulty readings.
Invalid EE CRC or Rev#	Calibration Failed Memory Error	Turn unit off and on again. If problem persists reload firmware or replace circuit board.
IChlr Com Er	IChlr Comm Error IntelliChlor- Communication Error	The IntelliChlor SCG device may not communicate if the water is too cold, not circulating, salt level is too low. It may also take from 2 to 10 minutes or more to begin communication. Sometimes this can be solved by cycling power to the IntelliChlor unit and waiting again. Check cable wires and terminals for proper connection.
pH/ORP Invalid Setup	Invalid Setting Invalid Hardware Config	This indicates incompatible settings in the pH setup. Check that the hardware configuration on pH Control page 1/2 and 2/2 correspond properly. That if you specify an internal pump, you've chosen one of the MTR_L/R devices, and if you've chosen an External doser, you've selected an external relay. Be sure you're not using the same output device for both pH and ORP or an alarm output. Check dosage, and supply settings. Check that if you are dosing by volume that you have provided the GPD of the doser.
pH/ORP Dose Limit	pH Dosage Limit ORP Dosage Limit pH Feed at Limit ORP Feed at Limit	If you are unable to resolve the problem, re-run the Auto Setup Wizard. When it prompts to use previous values be sure to choose Reset All. This alarm will be the normal course of water chemistry control when experiencing a heavier than expected bather load, high temperature, or improperly balanced water. First check the saturation index and balance the water chemistry. Increase the dosage and filter time, increase the daily limit. During peak loads it may be easiest to administer chemicals by hand. The Limit can be manually cleared in the pH/ORP Settings menu, accessed by the appropriate button to the left side of the LCD display. It can also be programmed to clear automatically each time the IntelliChem powers on, or at every 24 hours of continuous run time in the pH/ORP Dosage 2/2 menu.
pH >7.8 Lockout	PH Lock Out Sanitizer Feed Locked	This is a safety feature that prevents over feeding sanitizer if the pH gets too high. As pH increases, the sanitizer becomes less effective. The proper thing to do is first reduce the pH and then see if you really need to add more sanitizer. Often bringing down the pH is sufficient to free more sanitizer which will raise the ORP. The pH Lockout threshold is set in the Configuration/Preferences menu.
pH/ORP Check Probe	Check Probe(s) Probe Check Fail	The Open Probes Test is available in the Configuration/Diagnostics menu. Refer to troubleshooting guide for more details. The Configuration/Preferences menu allows you to turn on continuous probe checking. This tests the probes each time before dispensing any chemicals. This will help ensure that the measurements used to determine the dose were not a result of invalid measurements.

\*\* Displayed in various places on the main screen

## Troubleshooting the alarm messages

Flashing pH/ORP tank/hourglass symbol	Check pH Tank Check ORP Tank	Refill the chemical supply container and set the gauge to the appropriate corresponding level. This alarm indicates level is low and should be refilled. If non-fluid supply sources are used, like CO2 and SCG, you can set a reminder in the pH/ORP Supplies 2/2 menu that will trigger this alarm as a reminder to change CO2 canisters or clean the SCG plates. The reminder is reset either in the Supplies 2/2 menu or the pH/ORP Settings button.
ORP LOW	ORP Is Too Low ORP Reading Too Low	Increase filter time and increase dose size. This may be the result of the ORP Sensitivity setting. If the sensitivity is set to "Low", you may not have a sufficiently sized dose to reach the setpoint. Try turning Sensitivity to "High" or "Off".  Check overall water chemistry using the Saturation Index calculator or have water tested by a professional pool service person or dealer. Also, check that the dose dispensing device is operating properly and that your supply tank is full.
ORP HIGH	ORP Is Too High ORP Reading Too High	Overshooting ORP may simply be a result of Cyanuric acid in the pool which suppresses the ORP during the sunlight hours and releases chlorine at night. It may also be that dose size is set too high with insufficient mix time. Turning ORP Sensitivity to "Low" may help reduce overshooting.
pH LOW	PH Is Too Low pH Reading Too Low	Increase filter time and increase dose size. This may be the result of the pH Sensitivity setting. If the sensitivity is set to "Low", you may not have a sufficiently sized dose to reach the setpoint. Try turning Sensitivity to "High" or "Off".  Check overall water chemistry using the Saturation Index calculator or have water tested by a professional pool service person or dealer. Also, check that the dose dispensing device is operating properly and that your supply tank is full.
pH HIGH	PH Is Too High pH Reading Too High	Overshooting pH may be due to the dose size being set too high with insufficient mix time. Turning pH Sensitivity to "Low" may help reduce overshooting. Test overall water chemistry using the Saturation Index calculator. Low Total Alkalinity may contribute to rapid pH swings and make controlling water nearly impossible. Consult your pool professional.
NO FLOW DETECTED Check pump, flow cell, filter, and valves.	No Flow	Ensure the pool pump is turned on, that valves are properly positioned, and that sufficient water is being directed to the flow cell. Make sure the magnet is properly contained in the flow tube and that the detector is wired properly to the Flow switch terminal block. The flow switch should be closed (shorted) to indicate flow.  Warning: This is a Safety Device. Do not operate the IntelliChem with the flow switch bypassed. Water flow must be present to ensure chemicals are mixed adequately to avoid dangerous gasses and high concentrations of chemicals near people or pool equipment.
Awaiting FLOW DELAY	Flow Delay	This is not an alarm, only a message indicating that water chemistry control will commence after this count-down timer expires. To allow pool water to stabilize and time for chemicals to activate, a minimum of 15 minutes is required to get accurate readings. The Flow Delay is set in the Configuration/Delays menu. It is the combination of the Power-On and Flow-Switch delay settings. As a convenience for the pool service person, you may bypass the delay by holding the Up Arrow button for 3 seconds. Please give time for the water to stabilize before expecting proper operation of the equipment.
pH has priority	PH Priority	This is not an alarm but a message that pH is feeding (acid) and that ORP (chlorine) is on hold until the acid feed is finished. This is enabled in the Configuration/Dose Priority menu on systems where the acid and chlorine may be injecting near the same point in the plumbing and the installer has decided, for safety reasons, to only feed one chemical at a time.

\*\* Displayed in various places on the main screen

## Cross Reference

IntelliChem Alarm Name	Alarm bit	IntelliChem Message**	EasyTouch/IntelliTouch Message	Screen Logic Message
Scaling Corrosive	17	+53 Scaling	SI Scaling	SI Scaling
Corrosive	16	-41 Corrosive	SI Corrosive	SI Corrosive
UOC Comm Error	15	UOC Comm Err	Comlink Lost	Communication Lost
Calibration Failed	14	Auto Calib...Failed	Auto Cal Failed	Calibration Failed
Memory Error	13	Invalid EE CRC or Rev#	Memory Error	Memory Errors
IntelliChlor Comm Error	12	lChlr Com Er	lChlr Comm Error	IntelliChlor Communication Error
Invalid Setup	11	pH/ORP Invalid Setup	Invalid Setting	Invalid Hardware Config
ORP Dose Limit	10	ORP Dose Limit	ORP Dosage Limit	ORP Feed at Limit
PH Dose Limit	9	pH Dose Limit	PH Dosage Limit	pH Feed at Limit
PH Lockout	8	pH>7.8 Lockout	PH Lock Out	Sanitizer Feed Locked
Probe Check Fail	7	pH/ORP Check Probe	Check Probe(s)	Probe Check Fail
ORP Chemical Empty	6	Flashing ORP tank symbol	Check ORP Tank	Check ORP Tank
PH Chemical Empty	5	Flashing pH Tank symbol	Check PH Tank	Check pH Tank
ORP Low alarm	4	ORP LOW	ORP Is Too Low	ORP Reading Too Low
ORP High alarm	3	ORP HIGH	ORP Is Too High	ORP Reading Too High
PH Low alarm	2	pH LOW	PH is Too Low	pH Reading Too Low
PH High alarm	1	pH HIGH	PH is Too High	pH Reading Too High
No Flow Alarm	0	No Flow Detected...	No Flow	No Flow
<b>Status "alarm" conditions</b>	<b>Status bit</b>			
	9	Awaiting FLOW DELAY	Flow Delay	Flow Delay
	11	pH has priority	PH Priority	PH Priority

\*\* Displayed in various places on the main screen

## Tweaking pH (Calibrating)

Measure the pH using a standard test kit by taking several readings and averaging the results. To Tweak the pH sensor see page 12.

## Tweaking ORP (Calibrating)



**WARNING** Always make sure the pH is at the set point before calibrating ORP. Always control at PPM levels greater than 1.0 PPM when using ORP sensors.

**IMPORTANT:** For best results the ORP should be at the ORP set point when calibrating. For best results the PPM should be at the desired level when calibrating ORP. To Tweak the ORP sensor see page 15.

## IntelliChem Specifications

### RATINGS:

Input Voltage:	120 VAC / 240 VAC 50/60 Hz 200 mA / 100 mA or 0.2 A / 0.1 A
Relay Rating:	Dry Contact 5 A, 120 VAC / 30 VDC
Temperature:	Min./Max. Operating Temperature 30° - 110° F
Sensor Range:	pH 4.0 - 9.99 - ORP 0 - 999mV Flow Open or Closed

## MAINTENANCE

**Winterizing:** The Flow Cell sensors must be protected from freezing conditions. If the pool is winterized, plan to remove and store the sensors (as described above) as part of the normal pool winterizing process. The Flow Cell and related plumbing must be drained as well.

### Water Chemistry

Always test water chemistry with a quality manual test kit. Therefore, it may be preferable to calibrate pH using commercially available reference solutions. If required, use the IntelliChem Tweak pH feature to periodically adjust the pH reading (see page 52). It's important to note that changes in pH, cyanuric acid concentration, total dissolved solids, and use of additional or alternative sanitizers will all affect the primary sanitizer residual level relative to ORP. Maintain total alkalinity on regular basis to ensure pH stability. To maintain a consistent sanitizer residual in parts per million (ppm), periodically adjust the ORP level.

**Sensor Maintenance:** The Flow Cell sensors must be clean and free from oil, chemical deposits and contamination to function properly. After saturation in pool or spa water, the sensors may need to be cleaned on a weekly or monthly basis depending on bather load and other pool specific characteristics. Slow response, increased need to calibrate pH, and inconsistent readings are indications that the probes are in need of cleaning.

## MAINTENANCE (Continued)

**Cleaning the Flow Cell Sensors:** To clean the ORP and pH sensors, turn off the AC source power to IntelliChem at the GFCI switch. Disconnect the probe connectors from the Flow Cell, unscrew the probe and carefully remove them from the Flow Cell. Clean the reference junction (the white ring at the bottom of the probe body) with a soft toothbrush. A household liquid dish washing detergent may also be used to remove any oil. Rinse with fresh water and reinstall probes. If properly cleaned probes continue to provide unstable readings or require excessive calibration, the probes should be replaced. Probe Storage Exposure to atmospheric conditions will cause the probe tips to dry out. Store the sensors with the included plastic sensors storage caps if removed from the Flow Cell for more than one hour. If the storage caps have been misplaced, store the probes individually in small glass or plastic containers with clean water covering the sensor tips. Store sensors in a location that will not be subjected to freezing temperatures.

### Sensor Care

Contamination of the sensing elements often results in slow response and inaccurate readings. Clean the elements by the following procedures:

#### pH and ORP Sensors

1. Wash electrode tip in a liquid detergent and water. Carefully use a soft bristled toothbrush to wash the electrode tip and white sensing ring.
2. Rinse after cleaning. To install, place in flow cell according to the diagram and hand tighten.
3. Make sure the O-ring is installed on sensor.
4. If the cable is longer than needed, it should be coiled neatly and attached under the cabinet.

#### pH Sensors Only

5. Attempt to clean the sensor with liquid detergent first.
6. If this is not successful, swirl the tip of the sensor in a 5 parts water and 1 part muriatic acid solution for 10 - 20 seconds.
7. Rinse again and reinstall.

**WARNING Do not rub hard the glass element in the sensor or use sand paper or other polishing material to clean. HANDLE ELECTRODE CAREFULLY Sensors contain external and internal glass elements. Do not drop or otherwise subject the sensor to vibration, physical impact, or freezing conditions. ANY TYPE OF BREAKAGE IS NOT COVERED UNDER WARRANTY.**

**pH and ORP Sensors:** pH electrodes sense the acidity of the water and work with any acid or base. The blue bands on the cables identify the pH sensors. The red bands on the cables identify ORP sensors. Each sensor is also identified on the sensor body. ORP electrodes are used to monitor the Oxidation Reduction Potential (ORP is sanitization quality of the water) of a given solution. The sensing element of the ORP electrode is made of a precious metal such as platinum or gold.

**Sensors:** IntelliChem measures the following sensor measurements with the listed characteristics:

**pH Range:** 4.00 to 9.99

**ORP Range:** 0 to 999 mV

**Flow Switch:** This input measures if a switch is open or closed. Open is no water flow. A closed switch indicates flow.


## Motor Pump Head Tube Yearly Replacement

For best results, it is recommended to replace the IntelliChem motor(s) pump head tube(s) (P/N 521384Z) once a year.

### Pump Head Tube(s) Replacement (for single or multiple pumps):


**⚠ WARNING** Disconnect AC power to IntelliChem enclosure at the circuit breaker before servicing. Failure to do so could result in death or serious injury to serviceman, pool users or others due to electrical shock.

1. **STOP the main pool filter pump.**
2. First loosen the Jaco fitting on the OUTLET tube. Carefully disconnect the tube. Keep the tube pointed upward to keep the chemical from spilling out the top of the tube.
3. Connect the tube to the OUTLET of the new pump head Jaco fitting. Secure the tube.
4. Repeat Step 1 and 2 for the INLET tube.
5. Remove the upper and lower screws securing the old pump head and remove the pump head from the motor assembly.
6. Install the new pump head (with attached tubes) to the motor assembly. Secure the pump head with the two screws.




### IntelliChem Replacement Parts List

1. P/N 521465Z - Top Half (Lid with overlay and wiring diagram).
2. P/N 521319Z - IntelliChem Circuit Board.
3. P/N 8520031Z - Circuit Breaker.
4. P/N 521348Z - Pump head with tube, Jaco fittings and screws.
5. P/N 521466Z - Jaco fitting.
6. P/N 521467Z - Enclosure mounting brackets.
7. P/N 521338Z - Pump motor.
8. P/N 521468Z - Strain relief kit.



### IntelliChem Flow Cell Replacement Parts List

1. P/N 754000310 - Flow Cell with Flow Switch Sensors
2. P/N 744000260 - Sensor, pH
3. P/N 744000390 - Sensor, ORP
4. P/N 521342Z - IntelliChem Parts Bag





**READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL.  
SAVE THESE INSTRUCTIONS**



P/N 521363 Rev A