



Calibration & Usage – The Basics

Operational Buttons:



Key	Description
1	Push and hold to set the power to on or off.
2	Push to start a calibration. To exit a calibration, push and hold. Push and hold until "SET" shows on the display to go to the settings menu. To exit the settings menu, push and hold until "End" shows on the display. When in the settings menu, push to scroll through the settings. Note: Power cannot be set to off while in settings or calibration mode.
3	Push to set the lock feature to on or off. When the lock feature is on, the lock icon shows and the parameter value on the display does not change.

Operational Icons:



1 Calibration icon	4 Battery icon	7 Calibration standard expected ¹
2 Lock icon	5 Parameter value	8 Temperature
3 Parameter	6 Calibration standard measured for last calibration (high)	

¹ Shows during calibration

Icon	Description
	Shows the battery power level. Flashes when the battery power is less than 10%.
	Shows when the lock feature is on. When the lock feature is on, the parameter value on the display does not change. Push to set the lock feature to on or off.
	Shows when the tester is in calibration mode.

Calibration in 5 Easy Steps

1. Remove lid from tester. Fill with calibration solution to fill line (provided). Snap lid back on to tester.

2. Turn your tester on by pressing



3. Tap the center button on your tester to put the device into calibration mode



- Once the tester is in calibration mode this icon will appear in the corner
- Note: You cannot perform any other functions while tester is in calibration mode

4. Tap the center button again. The numbers on the display will begin to blink
5. The term "OK" will also momentarily appear above the calibration icon. The numbers will automatically reappear on the display screen.





YOUR TESTER IS NOW CALIBRATED & READY FOR USE

Helpful Hints:

- We anticipate that our Hach sensors will last above and beyond 2 years, depending on care & usage. To get the most out of your sensor, always keep a small amount of water in the cap when not in use.
- Here are a few tools in case you need additional assistance calibrating or using your testers:
 - To view our complete calibration demonstration, scan the code below with your smartphone. This video can also be found at www.aquachek.com.



- Additional support is also available by calling our technical assistance team at (800) 450-4248.
3. You can enter or exit the set up menu by pressing and holding the center button. Once in the set up menu, you can scroll through your options by tapping the center button. To change a setting within an

option, the  and  buttons serve as your "scroll" buttons. Simply tap the center button to accept the changes made within each option.

4. This tester comes with a multi-lingual Easy Set Up Guide (English, French, Spanish, Portuguese, Chinese, Japanese, Korean, & Thai). The full user manual is available for download in English or Spanish at www.hach.com.